

# **ERTMS/ETCS - Class 1**

# **ERTMS EuroRadio**Conformance Requirements

REF: SUBSET-092-1

ISSUE: 2.3.0

DATE: 06-Feb-2006

Company	Technical Approval	Management approval
ALSTOM		
ANSALDO		
BOMBARDIER		
INVENSYS		
SIEMENS		
THALES		



# 1. MODIFICATION HISTORY

Issue Number Date	Section Number	Modification / Description	Author
0.0.1 :: 3-Apr-02	first draft		J Harmer
0.0.2 :: 8-Apr-02	all	corrections	J Harmer
0.0.3 :: 15-Apr-02	all	corrections	J Harmer
0.0.4 :: 18-Apr-02	Section 2	Corrections to due handling of former "reserved" field, check of internal links	T Streich
0.0.5 :: 3-May-02	all	corrections after comments at sixth meeting	J Harmer
0.1.0 :: 10-May-02	none	clean version	J Harmer
2.2.1 :: 28-Jun-02	table 4.47	correction (TS) and issue	J Harmer
2.2.2. 31-03-03		Version number raised for release to the Users Group.	WLH
2.2.3 19-06-03	1.1,1.3, 3, Annex A, Annex B	Corrections for DB comments KMS deleted Reference updating	R Bertolini
2.2.4+ 25-06-03	2.5, Annex A, Annex B	Max DT/RQ/RP SaPDU lenght corrected; clarification on application of conformance requirements in Annex A and B	R.Bertolini
2.2.4++	editorial	For draft release to Users Group	JH
2.2.5	-	Formal release	JH
2.2.5.revA		Update to changes in ER	TS
31-08-2005		FIS issue 2.2.5.refF	
2.2.5.revB 15-09-2005		Changes during Zuerich meeting	TS
2.2.5.revC 21-10-2005		Comments from Bombardier added	TS
2.2.5.revD		corrections after comments	VP



09-11-2005		at Berlin meeting	
2.2.5.revE		corrections after comments	VP
25-01-2006		from Alcatel	
2.2.5.revF		corrections after comments	VP
02-02-2006		from Alcatel	
2.3.0	-	Formal release	VP
06-02-2006			
2.3.0	all sections	Template updated	JH
30-03-2009	renumbered		



# 2. TABLE OF CONTENTS

1.	MODII	FICATION HISTORY	2
2.	TABLE	OF CONTENTS	4
3.	TABLE	S	5
4.	INTRO	DUCTION	8
	4.1	Scope of the EuroRadio Conformance Specification	8
	4.2	General Notes on Conformance Requirements	g
	4.3	References	g
	4.4	Abbreviations and Definitions	12
5.	SAFE	TY PROTOCOL	15
	5.1	Supported service primitives	15
	5.2	Features of the safety layer	16
	5.3	Dynamic behaviour	17
	5.4	Format and Data Fields	19
	5.5	Error Treatment	23
	5.6	Configuration Parameters	27
6.	COMN	IUNICATION SERVICES AND PROTOCOLS	. 28
	6.1	Communications Services Conformance Requirements	. 28
	6.2	Supported Service Primitives	. 28
	6.3	Supported Parameters of Service Primitives	28
	6.4	Transport Protocol Conformance Requirements	31
	6.5	Network Protocol Conformance Requirements	. 38
	6.6	Data Link Protocol Conformance Requirements	39
	6.7	Management conformance requirements	46
A۱	NEX A	: INTERFACE TO MOBILE TERMINAL	48
ΔΝ	INEY R	· INTEREACE TO FIXED NETWORK	51



# 3. TABLES

Table 5.1 - Service Primitives       16         Table 5.2 - Safety layer features       17         Table 5.3 - Dynamic features       18         Table 5.4 - AU1 data fields       15         Table 5.5 - AU2 data fields       20         Table 5.5 - AU3 data fields       20         Table 5.7 - AR data fields       21         Table 5.8 - DT data fields       21         Table 5.9 - DI data fields       22         Table 5.9 - DI data fields       22         Table 5.10 - HP data fields       22         Table 5.11 - RQ data fields       23         Table 5.12 - RP data fields       23         Table 5.13 - Error treatment       26         Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       26         Table 6.3 - Connection Response       25         Table 6.4 - Connection Response       25         Table 6.5 - Data Request       30         Table 6.7 - Data Request       30         Table 6.9 - HP Data Request       30         Table 6.10 - HP Data Indication       30         Table 6.11 - Disconnection Request       30         Table 6.12 - Discon	Table 4.1 - Example of conformance requirements	9
Table 5.3 - Dynamic features.       15         Table 5.4 - AU1 data fields       15         Table 5.5 - AU2 data fields       20         Table 5.6 - AU3 data fields       21         Table 5.7 - AR data fields       21         Table 5.8 - DT data fields       21         Table 5.9 - DI data fields       22         Table 5.10 - HP data fields       22         Table 5.11 - RQ data fields       23         Table 5.12 - RP data fields       23         Table 5.13 - Error treatment       26         Table 6.1 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       28         Table 6.3 - Connection request       25         Table 6.4 - Connection Indication       25         Table 6.5 - Connection Response       25         Table 6.7 - Data Request       30         Table 6.8 - Data Indication       30         Table 6.9 - HP Data Request       30         Table 6.10 - HP Data Indication       30         Table 6.11 - Disconnection Indication       31         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.1 - Service Primitives	16
Table 5.4 - AU1 data fields       15         Table 5.5 - AU2 data fields       20         Table 5.6 - AU3 data fields       20         Table 5.7 - AR data fields       21         Table 5.8 - DT data fields       21         Table 5.9 - DI data fields       22         Table 5.10 - HP data fields       22         Table 5.11 - RQ data fields       23         Table 5.12 - RP data fields       23         Table 5.13 - Error treatment       26         Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       26         Table 6.3 - Connection Indication       26         Table 6.4 - Connection Response       29         Table 6.5 - Connection Response       29         Table 6.6 - Data Indication       30         Table 6.8 - Data Indication       30         Table 6.9 - HP Data Request       30         Table 6.10 - HP Data Indication       30         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.2 - Safety layer features	17
Table 5.5 - AU2 data fields       26         Table 5.6 - AU3 data fields       21         Table 5.7 - AR data fields       21         Table 5.8 - DT data fields       21         Table 5.9 - DI data fields       22         Table 5.10 - HP data fields       22         Table 5.11 - RQ data fields       23         Table 5.12 - RP data fields       23         Table 5.13 - Error treatment       26         Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       28         Table 6.3 - Connection request       29         Table 6.4 - Connection Indication       29         Table 6.5 - Connection Response       29         Table 6.6 - Data Indication       30         Table 6.8 - Data Indication       30         Table 6.9 - HP Data Request       30         Table 6.10 - HP Data Indication       30         Table 6.11 - Disconnection Indication       31         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.3 - Dynamic features	19
Table 5.6 - AU3 data fields       26         Table 5.7 - AR data fields       21         Table 5.8 - DT data fields       21         Table 5.9 - DI data fields       22         Table 5.10 - HP data fields       23         Table 5.11 - RQ data fields       23         Table 5.12 - RP data fields       23         Table 5.13 - Error treatment       26         Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       28         Table 6.3 - Connection request       29         Table 6.4 - Connection Indication       26         Table 6.5 - Connection Response       29         Table 6.6 - Connection Confirmation       30         Table 6.7 - Data Request       30         Table 6.9 - HP Data Indication       30         Table 6.10 - HP Data Indication       30         Table 6.12 - Disconnection Request       30         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.4 - AU1 data fields	19
Table 5.7 - AR data fields       21         Table 5.8 - DT data fields       21         Table 5.9 - DI data fields       22         Table 5.10 - HP data fields       22         Table 5.11 - RQ data fields       23         Table 5.12 - RP data fields       23         Table 5.13 - Error treatment       26         Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       28         Table 6.3 - Connection request       29         Table 6.4 - Connection Indication       29         Table 6.5 - Connection Response       29         Table 6.6 - Connection Confirmation       30         Table 6.7 - Data Request       30         Table 6.9 - HP Data Indication       30         Table 6.10 - HP Data Indication       30         Table 6.11 - Disconnection Request       30         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.5 - AU2 data fields	20
Table 5.8 - DT data fields       21         Table 5.9 - DI data fields       22         Table 5.10 - HP data fields       23         Table 5.11 - RQ data fields       23         Table 5.12 - RP data fields       23         Table 5.13 - Error treatment       26         Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       25         Table 6.3 - Connection request       25         Table 6.4 - Connection Indication       29         Table 6.5 - Connection Response       25         Table 6.6 - Connection Confirmation       30         Table 6.7 - Data Request       30         Table 6.9 - HP Data Indication       30         Table 6.10 - HP Data Indication       30         Table 6.11 - Disconnection Request       30         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.6 - AU3 data fields	20
Table 5.9 - DI data fields       22         Table 5.10 - HP data fields       22         Table 5.11 - RQ data fields       23         Table 5.12 - RP data fields       23         Table 5.13 - Error treatment       26         Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       28         Table 6.3 - Connection request       29         Table 6.4 - Connection Indication       29         Table 6.5 - Connection Response       29         Table 6.6 - Connection Confirmation       30         Table 6.7 - Data Request       30         Table 6.9 - HP Data Indication       30         Table 6.10 - HP Data Indication       30         Table 6.10 - HP Data Indication       30         Table 6.10 - HP Data Indication       30         Table 6.11 - Disconnection Request       30         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.7 - AR data fields	21
Table 5.10 - HP data fields       22         Table 5.11 - RQ data fields       23         Table 5.12 - RP data fields       23         Table 5.13 - Error treatment       26         Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       28         Table 6.3 - Connection request       29         Table 6.4 - Connection Indication       29         Table 6.5 - Connection Response       29         Table 6.6 - Connection Confirmation       30         Table 6.7 - Data Request       30         Table 6.9 - HP Data Indication       30         Table 6.10 - HP Data Indication       30         Table 6.10 - HP Data Indication       30         Table 6.11 - Disconnection Request       30         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.8 - DT data fields	21
Table 5.11 - RQ data fields       23         Table 5.12 - RP data fields       26         Table 5.13 - Error treatment       26         Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       28         Table 6.3 - Connection request       29         Table 6.4 - Connection Indication       29         Table 6.5 - Connection Response       29         Table 6.6 - Connection Confirmation       30         Table 6.7 - Data Request       30         Table 6.8 - Data Indication       30         Table 6.9 - HP Data Request       30         Table 6.10 - HP Data Indication       30         Table 6.10 - Disconnection Request       30         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.9 - DI data fields	22
Table 5.12 - RP data fields       23         Table 5.13 - Error treatment       26         Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       28         Table 6.3 - Connection request       29         Table 6.4 - Connection Indication       29         Table 6.5 - Connection Response       29         Table 6.6 - Connection Confirmation       30         Table 6.7 - Data Request       30         Table 6.8 - Data Indication       30         Table 6.9 - HP Data Request       30         Table 6.10 - HP Data Indication       30         Table 6.11 - Disconnection Request       30         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.10 - HP data fields	22
Table 5.13 - Error treatment       26         Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       28         Table 6.3 - Connection request       29         Table 6.4 - Connection Indication       29         Table 6.5 - Connection Response       29         Table 6.6 - Connection Confirmation       30         Table 6.7 - Data Request       30         Table 6.8 - Data Indication       30         Table 6.9 - HP Data Request       30         Table 6.10 - HP Data Indication       30         Table 6.11 - Disconnection Request       30         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.11 - RQ data fields	23
Table 5.14 - Configuration parameters       27         Table 6.1 - Communication services conformance requirements       28         Table 6.2 - Supported services primitives       28         Table 6.3 - Connection request       29         Table 6.4 - Connection Indication       29         Table 6.5 - Connection Response       29         Table 6.6 - Connection Confirmation       30         Table 6.7 - Data Request       30         Table 6.8 - Data Indication       30         Table 6.9 - HP Data Request       30         Table 6.10 - HP Data Indication       30         Table 6.11 - Disconnection Request       30         Table 6.12 - Disconnection Indication       31         Table 6.13 - Classes implemented       31	Table 5.12 - RP data fields	23
Table 6.1 – Communication services conformance requirements       28         Table 6.2 – Supported services primitives       28         Table 6.3 – Connection request       29         Table 6.4 – Connection Indication       29         Table 6.5 – Connection Response       29         Table 6.6 – Connection Confirmation       30         Table 6.7 – Data Request       30         Table 6.8 – Data Indication       30         Table 6.9 – HP Data Request       30         Table 6.10 – HP Data Indication       30         Table 6.11 – Disconnection Request       30         Table 6.12 – Disconnection Indication       31         Table 6.13 – Classes implemented       31	Table 5.13 - Error treatment	26
Table 6.2 – Supported services primitives       28         Table 6.3 – Connection request       29         Table 6.4 – Connection Indication       29         Table 6.5 – Connection Response       29         Table 6.6 – Connection Confirmation       30         Table 6.7 – Data Request       30         Table 6.8 – Data Indication       30         Table 6.9 – HP Data Request       30         Table 6.10 – HP Data Indication       30         Table 6.11 – Disconnection Request       30         Table 6.12 – Disconnection Indication       31         Table 6.13 – Classes implemented       31	Table 5.14 - Configuration parameters	27
Table 6.3 – Connection request       29         Table 6.4 – Connection Indication       29         Table 6.5 – Connection Response       29         Table 6.6 – Connection Confirmation       30         Table 6.7 – Data Request       30         Table 6.8 – Data Indication       30         Table 6.9 – HP Data Request       30         Table 6.10 – HP Data Indication       30         Table 6.11 – Disconnection Request       30         Table 6.12 – Disconnection Indication       31         Table 6.13 – Classes implemented       31	Table 6.1 – Communication services conformance requirements	28
Table 6.4 – Connection Indication       29         Table 6.5 – Connection Response       29         Table 6.6 – Connection Confirmation       30         Table 6.7 – Data Request       30         Table 6.8 – Data Indication       30         Table 6.9 – HP Data Request       30         Table 6.10 – HP Data Indication       30         Table 6.11 – Disconnection Request       30         Table 6.12 – Disconnection Indication       31         Table 6.13 – Classes implemented       31	Table 6.2 – Supported services primitives	28
Table 6.5 – Connection Response       29         Table 6.6 – Connection Confirmation       30         Table 6.7 – Data Request       30         Table 6.8 – Data Indication       30         Table 6.9 – HP Data Request       30         Table 6.10 – HP Data Indication       30         Table 6.11 – Disconnection Request       30         Table 6.12 – Disconnection Indication       31         Table 6.13 – Classes implemented       31	Table 6.3 – Connection request	29
Table 6.6 – Connection Confirmation       30         Table 6.7 – Data Request       30         Table 6.8 – Data Indication       30         Table 6.9 – HP Data Request       30         Table 6.10 – HP Data Indication       30         Table 6.11 – Disconnection Request       30         Table 6.12 – Disconnection Indication       31         Table 6.13 – Classes implemented       31	Table 6.4 – Connection Indication	29
Table 6.7 – Data Request       30         Table 6.8 – Data Indication       30         Table 6.9 – HP Data Request       30         Table 6.10 – HP Data Indication       30         Table 6.11 – Disconnection Request       30         Table 6.12 – Disconnection Indication       31         Table 6.13 – Classes implemented       31	Table 6.5 – Connection Response	29
Table 6.8 – Data Indication30Table 6.9 – HP Data Request30Table 6.10 – HP Data Indication30Table 6.11 – Disconnection Request30Table 6.12 – Disconnection Indication31Table 6.13 – Classes implemented31	Table 6.6 – Connection Confirmation	30
Table 6.9 – HP Data Request30Table 6.10 – HP Data Indication30Table 6.11 – Disconnection Request30Table 6.12 – Disconnection Indication31Table 6.13 – Classes implemented31	Table 6.7 – Data Request	30
Table 6.10 – HP Data Indication	Table 6.8 – Data Indication	30
Table 6.11 – Disconnection Request	Table 6.9 – HP Data Request	30
Table 6.12 – Disconnection Indication	Table 6.10 – HP Data Indication	30
Table 6.13 – Classes implemented31	Table 6.11 – Disconnection Request	30
	Table 6.12 – Disconnection Indication	31
Table 6.14 – Initiator/responder capability31	Table 6.13 – Classes implemented	31
	Table 6.14 – Initiator/responder capability	31



Table 6.15 – Supported functions	32
Table 6.16 – Supported TPDUs	33
Table 6.17 – Supported parameters of issued CR TPDU (ST1:)	33
Table 6.18 – Supported parameters of issued CC TPDU (ST3:)	33
Table 6.19 – Supported parameters of issued DR TPDU (ST5:)	33
Table 6.20 – Supported parameters of issued ER TPDU (ST14:)	34
Table 6.21 – User data in issued TPDUs	34
Table 6.22 – User data in received TPDUs	34
Table 6.23 – Class negotiation	34
Table 6.24 – TPDU size negotiation	35
Table 6.25 – TPDU size value	35
Table 6.26 – Use of extended format	35
Table 6.27 – Explicit flow control	35
Table 6.28 – Action on receipt of a protocol error	36
Table 6.29 – Action on receipt of an invalid or undefined parameter in a CR TPDU	36
Table 6.30 – Action on receipt of a CR TPDU parameter with invalid value	36
Table 6.31 – Actions on receipt of an invalid or undefined parameter in another TPDUs	36
Table 6.32 – Optional timers	37
Table 6.33 – Configuration parameter values	37
Table 6.34 – Co-ordinating function	38
Table 6.35 – Protocol capabilities	38
Table 6.36 – Configuration parameter values	38
Table 6.37 – Major capabilities	39
Table 6.38 – Supported functions	39
Table 6.39 – Options	40
Table 6.40 – Link setup	40
Table 6.41 – Link disconnection	41
Table 6.42 – Supported frame types	41
Table 6.43 – Frame structure	42
Table 6.44 – Interframe fill	42
Table 6.45 – Information transfer	43



Table 6.46 – Action on receipt of a protocol error	44
Table 6.47 – Actions on receipt of an invalid frame	45
Table 6.48 – Actions on timing out	46
Table 6.49 – Configuration parameters	46
Table 6.50 – Communication management	47
Table A1 - Supported signals	49
Table A2 - Supported functional properties	50
Table B1 - ISDN conformance requirements	51
Table B2 - Additional conformance requirements	52



# 4. Introduction

The objective of EuroRadio conformance testing is to establish whether the EuroRadio subsystem implementation being tested conforms to the EuroRadio Specification. The purpose of conformance testing is to provide assurance that different EuroRadio sub-system implementations are able to interwork.

To evaluate the conformance of a EuroRadio implementation with the EuroRadio Specification, it is necessary to have a statement of the conforming capabilities and implemented options. Such a statement is called an Implementation Conformance Statement (ICS). It has to be based on the conformance requirements contained in this specification.

Test cases are also required (see Subset-092-2[22]); they cover the safety layer only, as industry experience exists for the testing of the communications layer.

# 4.1 Scope of the EuroRadio Conformance Specification

This document consists of five technical sections:

- 4. General
- 5. Safety Protocol

This section provides the conformance requirements for the safety protocol specified in the EuroRadio Specification [20].

6. Communication Services and Protocols

This section provides the conformance requirements for the communication protocols specified in the EuroRadio Specification [20].

Annex A: Interface to the Mobile Network

The requirements for this interface are optional. That is, this interface may be closed, using a manufacturer-specific interface, or open, when the requirements of the EuroRadio specification must be complied with. This section covers the conformance requirements for connecting an on-board EuroRadio sub-system equipment to a GSM mobile terminal.

Annex B: Interface to the Fixed Network

This section provides guidelines for trackside EuroRadio sub-system equipment to connect to an ISDN using ISDN primary rate access. This section is optional, not mandatory.

Note that performance requirements on EuroRadio are currently excluded from this conformance specification, as they are specified at the system level.



# 4.2 General Notes on Conformance Requirements

#### 4.2.1 Questions

The conformance requirements are specified in the form of a questionnaire. Each question in the conformance chapters refers to a feature of the service or protocol which requires an answer by conformance testing.

Answering 'YES' to a particular question states that the implementation supports the features defined in the referenced sections of the EuroRadio Specification. Answering 'NO' to a particular question states that the implementation does not support that feature. For some questions a value, a range of values, or an action shall be provided by the implementer.

Some of the items are optional and in some cases the option is dependant on the implementation of other items. In these cases, if the invoking capability is supported, the ability to support the item is mandatory. These conditions are made clear in the text of each item.

#### 4.2.2 Conventions

The questions are presented in the form of tables. Table 4-1 contains examples.

Item	Function	References	Status	Supported
CoS1	Connection set up	[20] 8.1.2	М	Yes
CoSP1	T-CONNECT.request	[20] B.1	0	Yes No
CoCRQ1	Called address	[20] B.1	CoSP1:M	Yes

#### Table 4.1 - Example of conformance requirements

The following conventions apply:

**Item** a unique reference for the requirement

Function an abbreviation of the requirement; for more details see the reference

**Reference** the specification reference as [x], followed by the section.

#### **Status**

M For supported functions:

It is *mandatory* that the function is implemented and always used. The function shall be tested.

For supported parameters:

It is mandatory that the parameter is implemented. For transmission the parameter shall always be sent and for reception the parameter shall be correctly processed and acted upon. The parameter shall be tested. Where more than one value of the parameter is allowed, all must be supported.

O For supported functions:



It is *optional* whether the function is implemented. If implemented the feature may or may not be used. The function shall be tested.

For supported parameters:

It is optional whether the parameter is implemented. For transmission, if the parameter is implemented, then it may sometimes be sent. The parameter shall be tested.

N/A The function is *not applicable* and shall not be tested.

For supported parameters:

For transmission the parameter shall never be sent. For reception the parameter shall be ignored or a protocol error shall be generated.

O.<n> Optional but support of at least one or only one of the groups of options labelled by the same numeral <n> in this PICS proforma is required.

<item>: This predicate symbol means that the status following it applies only when the PICS states that the feature identified by the index is supported. In the simplest case, <item> is the identifying tag of a single PICS item. <item> may also be a Boolean expression composed of several indices.

<index>:: When this group predicate is true the associated clause should be completed. Possible groups are RBC (true for all radio block centres) or OBU (true for all onboard units).

**Supported** the implementer must answer 'Yes' or 'No' in the supported column

#### 4.2.3 General Statement of Conformance

The general statement of conformance to be answered by implementation suppliers is:

Are all mandatory features of EuroRadio Specification implemented?

NOTE – Answering "No" to this question indicates non-conformance to the EuroRadio Specification.

#### 4.3 References

This specification references to dated standards and specifications. Subsequent amendments to or revisions of any these specifications apply to this specification only when incorporated in it by amendment or revision.

- [1] ENV 41 001: ISDN connector up to 8 pins and up to 2,048 Mbit/s
- [2] ETS 300 011 (April 92) and Amendment A2 (March 1996) ISDN; Primary rate user-network interface; Layer 1 Specification and test principles



- [3] ETS 300 046 (August 92)
  - ISDN; Primary rate access; Safety and protection
    - Part 1: General
    - Part 2: Interface I<sub>a</sub>; Safety Part 3: Interface I<sub>a</sub>; Protection
- [4] ETS 300 102-1 (December 1990), Amendment A1 (April 1993) and Amendment A2 (October 1993): ISDN; User-network interface layer 3; Specifications for basic call control
- [5] ETS 300 125 (September 1991): ISDN; User-network interface data link layer specification; Application of CCITT Recommendations Q.920/I.440 and Q.921/I.441
- [6] ETS 300 156 (September 92) and Amendment A1 (March 1995) ISDN; Attachment requirements for terminal equipment to connect to an ISDN using ISDN primary rate access
- [7] ETS 300 306 (December 1994) ISDN; Digital Subscriber Signalling System No. 1 (DSS1); Protocol Implementation Conformance Statement (PICS) proforma specification for data link layer protocol for general application (primary rate access, user)
- [8] ETS 300 310 (May 1995) ISDN; Digital Subscriber Signalling System No. 1 (DSS1); Partial Protocol Implementation eXtra Information for Testing (PIXIT) proforma specification for data link layer protocol for general application (primary rate access, user)
- [9] ETS 300 315 (December 1994) ISDN; Digital Subscriber Signalling System No. 1 (DSS1); Protocol Implementation Conformance Statement (PICS) proforma specification for signalling network layer protocol for circuit-mode basic call control (primary rate access, user)
- [10] ETS 300 319 (May 1995) ISDN; Digital Subscriber Signalling System No. 1 (DSS1); Partial Protocol Implementation eXtra Information for Testing (PIXIT) proforma specification for signalling network layer protocol for circuit-mode basic call control (primary and basic rate access, user)
- [11] ISO 3309(12.93) HDLC procedures; Frame structure
- [12] ISO 4335(12.93) HDLC procedures; Elements of Procedures
- [13] ISO 7776(07.95) Description of the X.25 LAPB-compatible DTE data link procedure
- [14] ISO 7809(12.93) HDLC procedures; Classes of Procedures
- [15] ITU-T Rec. I.431 (03/93) ISDN; Primary rate user-network interface; Layer 1 Specification
- [16] ITU-T Rec. T.70 (03/93) Network independent basic transport service for telematic services
- [17] ITU-T Rec. X.224 (11/93); Information technology- Open System Interconnection- Protocol for providing the OSI Connection-mode Transport service



- [18] ITU-T Rec. X.290 (January 1992): OSI conformance testing methodology and framework for protocol recommendations for CCITT applications General concepts
- [19] prETS 300 582 (December 1995): European digital cellular telecommunications system (Phase 2); General on Terminal Adaptation Functions (TAF) for Mobile Stations (MS). (GSM 07.01)
- [20] ERTMS/ETCS Class 1: Subset-037, EuroRadio FIS, issue 2.3.0
- [21] ERTMS/ETCS Class 1: Subset-026, System Requirements Specification, issue 2.2.2
- [22] ERTMS/ETCS Class 1: Subset 092-2, ERTMS EuroRadioTest cases Safety Layer, issue 2.3.0
- [23] UIC/UNISIG EURORADIO INTERFACE GROUP: Radio Transmission FFFIS A11T6001.12 version referenced by TSI
- [24] prETS 300 914 (February 1998): Digital cellular telecommunications system (Phase 2+); Terminal Adaptation Functions (TAF) for services using asynchronous bearer capabilities (GSM 07.02)
- [25] prETS 300 915 (February 1998): Digital cellular telecommunications system (Phase 2+); Terminal Adaptation Functions (TAF) for services using synchronous bearer capabilities (GSM 07.03)
- [26] TS 100 916 (Rel.1998): Digital cellular telecommunications system (Phase 2+); AT command set for GSM Mobile Equipment (ME) (GSM 07.07)
- [27] ETS 300403-1 (November 1995): Integrated Services Digital Network (ISDN) Digital Subscriber Signalling System No. one (DSS1) protocol Signalling network layer for circuit-mode basic call control Part 1

## 4.4 Abbreviations and Definitions

For the purposes of this specification the abbreviations and definitions of [20] apply.

#### 4.4.1 General

ATS	Abstract Test Suite
IUT	Implementation Under Test
PCO	Point of Controls and Observations
PICS	Protocol Implementation Conformance Statement
PIXIT	Protocol Implementation eXtra Information for Testing
QoS	Quality of Service

Additionally, some layer specific terms and abbreviations apply.

#### 4.4.2 Layer 4

AK Acknowledgement



CC Connect Confirmation

CONS Connection Oriented Network Service

CR Connect Request

DC Disconnect Confirmation
DR Disconnect Request

DT Data

EA Expedited Acknowledgement

ED Expedited Data

ER Error

HP High Priority

SAP Service Access Point

TPDU Transport Protocol Data Unit

TSAP-ID Transport Service Access Point IDentifier

## 4.4.3 Layer 2

DISC Disconnect

DM Disconnect Mode

FCS Frame Check Sequence

FRMR Frame Reject

LAPB Link Access Procedure - Balanced

REJ Reject

SABME Set Asynchronous Balanced Mode Extended

UA Unnumbered Acknowledgement

UI Unnumbered Information XID eXchange IDentification



## 4.4.4 Definitions

Term	Definition
Protocol Implementation Conformance Statement	A statement made by the supplier of an implementation or system, stating which capabilities have been implemented (refer to X.290 [18])
Protocol Implementation extra information for testing	A statement made by the supplier or implementer of an implementation under test (IUT), which contains or references all of the information (in addition to that given in the PICS) related to the IUT and its testing environment, which will enable the test laboratory to run an appropriate test suite against the IUT.
Abstract Test Suite	as defined in X.290 [18]
Compatibility testing	The task to provide a level of confidence that two implementations of the protocol are compatible.
Conformance clause (Conformance requirement)	An elementary piece of a specification stating what an implementation is required to do or not to do.
Conformance Statement	The statement which services or protocols are claimed to be implemented and to which implementation options are supported.
Conformance testing standard	ITU-T Recommendation or International Standard that contains a standardised abstract test suite.
Implementation Under Test	as defined in X.290 [18]
PICS proforma	A document, in the form of a questionnaire, designed by the protocol specifier or the conformance test suite specifier, which when completed for an implementation or system becomes the PICS.
PIXIT proforma	A document, in the form of a questionnaire, provided by the test laboratory, which when completed during the preparation for testing becomes the PIXIT.
Point of Controls and Observations	as defined in X.290 [18]




# 5. SAFETY PROTOCOL

The following tables include the PICS for the safe functional module according to the EuroRadio FIS. The reference column refers to the corresponding section of this FIS [20].

Status shows the requirement for realisation of the feature, support indicates the behaviour of external requests.

The following figure shows the EuroRadio safety layer (implementation under test) and the position of the interfaces which are recommended points of control and observation.



PCO = Point of control and observation

Figure 1 Points of control and observation for the EuroRadio safety layer

# 5.1 Supported service primitives

The following services are required at the point of control and observation between the EuroRadio and the application (safety services user). The mentioned services are mandatory, the services are required at a functional level only; conformance of the interface is not required.



Item	Service	Reference	Status	Support
Sa 1	Establish a safe connection	[20] 5.2	М	Yes
Sa 2	Indication of safe connection establishment	[20] 5.2	М	Yes
Sa 3	Response to indicated connection establishment	[20] 5.2	M	Yes
Sa 4	Confirmation of safe connection establishment	[20] 5.2	M	Yes
Sa 5	Safe data transfer (send)	[20] 5.3	М	Yes
Sa 6	Safe data transfer (receive)	[20] 5.3	М	Yes
Sa 7	Release a safe connection	[20] 5.4	М	Yes
Sa 8	Indication of safe connection release	[20] 5.4	М	Yes
Sa 9	Error indication	[20] 5.5	0	Yes No
Sa 10	High priority data transfer (send)	[20] 5.6	RBC:: M	Yes
		[21]	OBU :: O	Yes No
Sa 11	High priority data transfer (receive)	[20] 5.6	OBU:: M	Yes
		[21]	RBC:: O	Yes No
Sa106	Initiate network registration	[20] 5.7	OBU:: M	Yes
			RBC:: N/A	No
Sa107	Receive a network registration status	[20] 5.7	OBU:: M	Yes
			RBC:: N/A	No

**Table 5.1 - Service Primitives** 

# 5.2 Features of the safety layer

ltem	Feature	Reference	Status	Support
Sa 12	evaluation of the parameter safety features	[20] 7.2.3.2.6	М	Yes
Sa 13	calculation of a 168 bit long session key (KSMAC) from Authentication key (KMAC) and random numbers	[20] 7.2.2.2.4.11	М	Yes
Sa 14	Message Origin Authentication on Transmission <sup>1</sup>	[20] 7.2.2.2.1	М	Yes
Sa 15	Message Origin Authentication on	[20] 7.2.2.2.1	М	Yes

<sup>&</sup>lt;sup>1</sup> Test of this feature can be combined with Items Sa 43, Sa 47, Sa 51 and Sa 56 (also Sa 69 and Sa 76 if used).



ltem	Feature	Reference	Status	Support
	Reception <sup>2</sup>			
Sa 16	padding (done during MAC calculation) <sup>3</sup>	[20] 7.2.2.2.1	M	Yes
Sa 17	Addressing (network address) during safe connection set-up	[20] 7.1.3.2	M	Yes
Sa 18	QoS-handling during safe connection set-up	[20] 7.1.3.2	M	Yes
Sa 108	Network Registration request and indication are forwarded	[20] 5.7.1.3	OBU:: M RBC:: N/A	Yes No

#### Table 5.2 - Safety layer features

Note: Peer entity identification is realised by the following items:

- Successful procedure (outgoing request): Sa 19, Sa 20

Successful procedure (incoming request): Sa 22, Sa 23

Error case (incoming request): Sa 82

Error case (outgoing request): Sa 81

# 5.3 Dynamic behaviour

This section describes several protocol features which are related to the internal behaviour of the safety protocol. The description of the feature is related to the EuroRadio FIS [20], section 7.2.5.

Each of the following protocol features assumes that the protocol is in a certain internal state. According to the FIS state table (table 23 of [20]), incoming events require a certain reaction. This reaction shall be shown by the IUT.

The following item description therefore starts with the initial internal state, and describes the succeeding event; sometimes limiting conditions (constraints) are added. The action performed by the IUT should be checked and compared with the defined action according to the EuroRadio FIS [20], stated preconditions should be fulfilled. Agreement between the defined action and the behaviour of the IUT is required.

The error treatment and handling of main errors related to peer entity identification is included in section 5.5.

© This document has been developed and released by UNISIG

SUBSET-092-1 ERTMS EuroRadio Page 17/52 2.3.0 Conformance Requirements

<sup>&</sup>lt;sup>2</sup> Test of this feature can be combined with Items Sa 43, Sa 47, Sa 51 and Sa 56 (also Sa 69 and Sa 76 if used).

<sup>&</sup>lt;sup>3</sup> Test of this feature can be combined with Items Sa 43, Sa 47, Sa 51 and Sa 56 (also Sa 69 and Sa 76 if used).



Item	Feature	Reference	Status	Support
Sa 19	T-CONN.req with AU1 SaPDU, when in state IDLE an event Sa-Conn.Req occurs (correct KMAC for requested ETCS-ID is available).	[20] 7.2.5.3	М	Yes
Sa 20	AU3 SaPDU, when in state WFTC an event AU2 SaPDU (received by T-Conn.conf, correct KMAC for requested ETCS-ID is available) occurs.	[20] 7.2.5.3	М	Yes
Sa 21	Sa-CONN.conf, when in state WFAR an event AR SaPDU occurs.	[20] 7.2.5.3	M	Yes
Sa 22	T-CONN.resp with AU2 SaPDU, when in state IDLE an event AU1 SaPDU (received by T-Conn.ind, KMAC for requested ETCS-ID is available) occurs.	AU1 ind,		Yes
Sa 23	Sa-CONN.ind, when in state WFAU3 an event AU3 SaPDU occurs.	[20] 7.2.5.3	M	Yes
Sa 24	AR SaPDU, when in state WFRESP an event Sa-Conn.resp occurs.	[20] 7.2.5.3	[20] 7.2.5.3 M	
Sa 25	Sa-Data.ind, when in state DATA an event DT SaPDU occurs.	[20] 7.2.5.3	[20] 7.2.5.3 M	
Sa 26	DT SaPDU, when in state DATA an event Sa-DATA.req occurs.	[20] 7.2.5.3	[20] 7.2.5.3 M	
Sa 27	Sa-HP-DATA.ind, when in state DATA an event HP SaPDU occurs.	[20] 7.2.5.3 OBU::M RBC::O		Yes YES NO
Sa 28	HP SaPDU, when in state DATA an event Sa-HP-DATA.req occurs.	[20] 7.2.5.3	OBU: O RBC: M	Yes NO YES
Sa 29	Sa-DISC.ind, when in state DATA an event DI SaPDU(received by T-Disc.ind) occurs.	[20] 7.2.5.3	М	Yes



Item	Feature	Reference	Status	Support
Sa 30	T-DISC.req with DI SaPDU, when in state DATA an event Sa-Disc.req occurs.	[20] 7.2.5.3	М	Yes

**Table 5.3 - Dynamic features** 

## 5.4 Format and Data Fields

All the following data fields (DF) have to be compliant to the following tables during sending and receiving of the corresponding SaPDU.

#### 5.4.1 AU1 SaPDU

Item	Data Field	Reference	Allowed values (bit)	Status	Support
Sa 31 A	sub-field ETY	[20]	001	OBU:: M	Yes
В		7.2.4.2.2	010	RBC:: M	Yes
С			101	0	Yes No
D			110	0	Yes No
Sa 32	sub-field MTI	[20] 7.2.4.2.2	0001	М	Yes
Sa 33	sub-field direction flag	[20] 7.2.2.2.1.17, 7.2.4.2.2	0	M	Yes
Sa 34	sub-field calling ETCS-ID	[20] 7.2.4.2.2	4	M	Yes
Sa 35	sub-field safety feature	[20] 7.2.4.2.2	0000 0001	М	Yes
Sa 36	sub-field random number R <sub>B</sub>	[20] 7.2.4.2.2	64 bit	М	Yes

Table 5.4 - AU1 data fields

<sup>&</sup>lt;sup>4</sup> according to NID\_ENGINE or RBC ETCS identity (given by NID\_C+NID\_RBC) of [21]



## 5.4.2 AU2 SaPDU

Item	Data Field	Reference	Allowed values	Status	Support
			(bit)		
Sa 37 A	sub-field ETY	[20]	001	OBU:: M	Yes
В		7.2.4.2.3	010	RBC:: M	Yes
С			101	0	Yes No
D			110	0	Yes No
Е			000	0	Yes No
Sa 38	sub-field MTI	[20] 7.2.4.2.3	0010	М	Yes
Sa 39	sub-field direction flag	[20] 7.2.2.2.1.17, 7.2.4.2.3	1	M	Yes
Sa 40	sub-field Responding ETCS-ID	[20] 7.2.4.2.3	5	M	Yes
Sa 41	sub-field safety feature	[20] 7.2.4.2.3	0000 0001	М	Yes
Sa 42	sub-field random number R <sub>A</sub>	[20] 7.2.4.2.3	64 bit	М	Yes
Sa 43	MAC field	[20] 7.2.2.2.1 7.2.4.2.3	64 bit	M	Yes

Table 5.5 - AU2 data fields

## 5.4.3 AU3 SaPDU

Item	Data Field	Reference	Allowed values (bit)	Status	Support
Sa 44	Bit 8,7,6 of the first octet	[20] 7.2.4.2.4	000	М	Yes
Sa 45	sub-field MTI	[20] 7.2.4.2.4	0011	М	Yes
Sa 46	sub-field direction flag	[20] 7.2.2.2.1.17, 7.2.4.2.4	0	М	Yes

<sup>&</sup>lt;sup>5</sup> according to NID\_ENGINE or RBC ETCS identity (given by NID\_C+NID\_RBC) of [21]



Item	Data Field	Reference	Allowed values (bit)	Status	Support
Sa 47	MAC field	[20] 7.2.2.2.1	64 bit	M	Yes
		7.2.4.2.4			

Table 5.6 - AU3 data fields

## 5.4.4 AR SaPDU

Item	Data Field	Reference	Allowed values (bit)	Status	Support
Sa 48	Bit 8,7,6 of the first octet	[20] 7.2.4.2.5	000	М	Yes
Sa 49	Sub-field MTI	[20] 7.2.4.2.5	1001	М	Yes
Sa 50	Sub-field direction flag	[20] 7.2.2.2.1.17, 7.2.4.2.5	1	M	Yes
Sa 51	MAC field	[20] 7.2.2.2.1 7.2.4.2.5	64 bit	М	Yes

Table 5.7 - AR data fields

## 5.4.5 DT SaPDU

Item	Data Field	Reference	Allowed values	Status	Support
			(bit)		
Sa 52	Bit 8,7,6 of the first octet	[20]	000	М	Yes
		7.2.4.3.1			
Sa 53	sub-field MTI	[20]	0101	М	Yes
		7.2.4.3.1			
Sa 54 A	sub-field direction flag	[20]	0 (initiator)	М	Yes
В		7.2.2.2.1.17,	1 (responder)	М	Yes
		7.2.4.3.1			
Sa 55	user data	7.2.4.3.1	11023 octet	М	Yes
Sa 56	MAC field	[20]	64 bit	М	Yes
		7.2.2.2.1			
		7.2.4.3.1			



## Table 5.8 - DT data fields

## 5.4.6 DI SaPDU

Item	Data Field	Reference	Allowed values (bit)	Status	Support
Sa 57	Bit 8,7,6 of the first octet	[20] 7.2.4.4.1	000	М	Yes
Sa 58	sub-field MTI	[20] 7.2.4.4.1	1000	М	Yes
Sa 59 A B	sub-field direction flag	[20] 7.2.2.2.1.17, 7.2.4.4.1	0 (initiator) 1 (responder)	M M	Yes Yes
Sa 60	sub-field reason	[20] 7.2.4.4.1	8 bit	М	Yes
Sa 61	sub-field sub-reason	[20] 7.2.4.4.1	8 bit	М	Yes

#### Table 5.9 - DI data fields

## 5.4.7 HP SaPDU

Item	Data Field	Reference	Allowed values (bit)	Status	Support
Sa 62	user data	[20] 7.2.4.5.1, 7.1.7.2	125 octets	М	Yes

#### Table 5.10 - HP data fields

#### 5.4.8 RQ SaPDU

Data Field		Reference	Allowed values	Status	Support
sub-field ETY		[20]	001	0	Yes No
		C.1.1.1.9	010	0	Yes No
			101	0	Yes No
			000	0	Yes No
			110	0	Yes No
sub-field Message	Туре	[20]	1011	0	Yes No
	sub-field ETY	sub-field ETY sub-field Message Type	sub-field ETY [20] C.1.1.1.9  sub-field Message Type [20]	Sub-field ETY [20] 001 C.1.1.1.9 010 101 000 110 Sub-field Message Type [20] 1011	Sub-field ETY [20] 001 O C.1.1.1.9 010 O 101 O 1



Item	Data Field	Reference	Allowed values	Status	Support
Sa 65 A	sub-field direction flag	[20]	0 (initiator)	0	Yes No
В		7.2.2.2.1.17,	1 (responder)	0	Yes No
		C.1.1.1.9			
Sa 66	sub-field identifier	[20]	8 bit	0	Yes No
		C.1.1.1.9			
Sa 67	sub-field sub-type of	[20]	8 bit	0	Yes No
	message	C.1.1.1.9			
Sa 68	sub-field data	[20]	11021 octets	0	Yes No
		C.1.1.1.9			
Sa 69	MAC field	[20]	64 bit	0	Yes No
		7.2.2.2.1.17			
		C.1.1.1.9			

Table 5.11 - RQ data fields

## 5.4.9 RP SaPDU

Item	Data Field	Reference	Allowed values	Status	Support
Sa 70 A	sub-field ETY	[20]	001	0	Yes No
В		C.1.1.1.9	010	0	Yes No
С			101	0	Yes No
D			000	0	Yes No
E			110	0	Yes No
Sa 71	sub-field MTI	[20] C.1.1.1.9	1100	0	Yes No
Sa 72 A	sub-field direction flag	[20]	0 (initiator)	0	Yes No
В		7.2.2.2.1.17,	1 (responder)	Ο	Yes No
		C.1.1.1.9			
Sa 73	sub-field identifier	[20]	8 bit	0	Yes No
		C.1.1.1.9			
Sa 74	sub-field sub-type of	[20]	8 bit	0	Yes No
	message	C.1.1.1.9			
Sa 75	sub-field data	[20]	1 1021 octets	0	Yes No
		C.1.1.1.9			
Sa 76	MAC field	[20]	64 bit	0	Yes No
		7.2.2.2.1.17			
		C.1.1.1.9			



Table 5.12 - RP data fields

## 5.5 Error Treatment

The compliance of treatment of transport protocol errors is detailed in section 6.4.4 and data link protocol errors in section 6.6.4.

ltem	Required treatment / error event	Reference	Status	Support
Sa 77A	Sa-Disc.ind, when Sa-Conn.req from application contains a wrong application type	[20] 7.2.5.3	M	Yes
Sa 77B	T-DISC.req, when T-Conn.ind from network contains a wrong application type	[20] 7.2.5.3	М	Yes
Sa 78	T-DISC.req,, when in state IDLE an event T-Conn.ind (incl. correct AU1 SaPDU, no KMAC for calling ETCS-ID available) occurs.	[20] 7.2.5.3	M	Yes
Sa 79	Sa-DISC.ind & T-DISC.req, when the receiving ETCS-ID (in the AU2) is not the requested ETCS-ID (requested ETCS-ID different from unknown)	[20] 7.3.3.5	M	Yes
Sa 80	Sa-DISCONNECT.indication if no transport service available	[20] 7.3.3.5	M	Yes
Sa 81	Sa-DISC.ind & T-DISC.req, when in state WFTC an event T-Conn.conf (incl. wrong MAC of AU2 SaPDU) occurs.	[20] 7.3.3.5 7.2.5.3	M	Yes
Sa 82	T-DISC.req, when in state WFAU3 an event T-Data.ind (incl. wrong MAC of AU3 SaPDU) occurs.	[20] 7.3.3.5 7.2.5.3	M	Yes
Sa 83	Sa-DISC.ind & T-DISC.req in case of failure in the verification of the CBC_MAC of a AR SaPDU	[20] 7.3.3.5 7.2.5.3	M	Yes
Sa 84	Sa-REPORT.ind in case of failure in the verification of the CBC_MAC of a DT SaPDU	[20] 7.3.3.5	M	Yes
Sa 85	T-DISC.req in case of failure in the direction flag of a AU 1 SaPDU	[20] 7.3.3.5	M	Yes
Sa 86	Sa_DISC.ind in case of failure in the	[20] 7.3.3.5	М	Yes



Item	Required treatment / error event	Reference	Status	Support
	direction flag of DI SaPDU			
Sa 87	Sa_DISC.ind in case of failure in the direction flag of	[20] 7.3.3.5		
Α	- AU2 SaPDU		М	Yes
В	- AU3 SaPDU		M	Yes
С	- AR SaPDU		М	Yes
D	- DT SaPDU		М	Yes
E			S65A:M	Yes No
	- RQ SaPDU		S65B:M	Yes No
F			S72A:M	Yes No
	- RP SaPDU		S72B:M	Yes No
Sa 88	Correct response to invalid value inside field "bit 8,7,6 of the first octet" in	[20] 7.3.3.5		
Α	AU3 SaPDU,		М	Yes
В	AR SaPDU,		М	Yes
С	DT SaPDU,		М	Yes
D	DI SaPDU		М	Yes
Sa 89	T-DISC.req in case of invalid SaPDU	[20] 7.2.5.3	М	Yes
	field:	7.3.3.5		
	- wrong ETY field in AU1 SaPDU			
Sa 90	Sa-DISC.ind & T-DISC.req in case of	[20] 7.2.5.3	М	Yes
	invalid SaPDU field:	7.3.3.5		
	- wrong ETY field in AU2 SaPDU			
Sa 91	Correct response to invalid SaPDU	[20] 7.2.5.3	M	Yes
	field:	7.3.3.5		
	- wrong MTI field			
Sa 92	T-DISC.req in case of invalid SaPDU	[20] 7.2.5.3	M	Yes
	field:	7.3.3.5		
	<ul> <li>wrong safety feature field in AU1 SaPDU</li> </ul>			
Sa 93	Sa-DISC. ind & T-DISC.req in case	[20] 7.2.5.3	М	Yes
	of invalid SaPDU field:	7.3.3.5		
	<ul> <li>wrong safety feature field in AU2 SaPDU</li> </ul>			



Item	Required treatment / error event	Reference	Status	Support
Sa 94	Correct response to failure in the sequence of SaPDUs during connection set up, respectively	[20] 7.2.3.5, 7.2.5.3		
А	- first message inside T_Conn.ind is not AU 1		M	Yes
В	- T-Conn.ind does not contain user data		M	Yes
С	- Message after AU1 isn't AU2		М	Yes
D E	- T-Conn.conf does not contain user data		M	Yes
F			M	Yes
	- Message after AU2 isn't AU3		M	Yes
Sa 95	<ul> <li>Message after AU3 isn't AR</li> <li>Correct response to SaPDU too short, i.e. fields are missing</li> </ul>	[20] 7.3.3.5		
А	- AU1 SaPDU too short		M	Yes
В	- AU2 SaPDU too short		М	Yes
С	- AU3 SaPDU too short		М	Yes
D	- AR SaPDU too short		М	Yes
E	DT SaPDU shorter than 10 bytes		M	Yes
Sa 96	Correct response to SaPDU too long	[20] 7.3.3.5		
А	- AU1 SaPDU too long		М	Yes
В	- AU2 SaPDU too long		М	Yes
С	- AU3 SaPDU too long		М	Yes
D	- AR SaPDU too long		M	Yes
E	- DT SaPDU longer than 1032 bytes		M	Yes
Sa 97	Sa-DISC.ind & T-DISC.req if an event timeout T <sub>estab</sub> in state WFTC occur.	[20] 7.2.5.3	M	Yes
Sa 98	Sa-DISC.ind & T-DISC.req if an event timeout T <sub>estab</sub> in state WFAR occur.	[20] 7.2.5.3	M	Yes



Item	Required treatment / error event	Reference	Status	Support
Sa 99	Correct response to failure in key calculation	[20] 7.2.5.3 7.3.3.5	M	Yes

Table 5.13 - Error treatment

Note: not all error cases are included:

- no sub-reasons to reason code 1 (only Sa 80)
- no check of a wrong application type of a T-Conn.ind included
- T-DISC.ind (Indication of connection loss) and Sa-DISC.req (Cancelation of establishment by user) during Peer Entity Identification

# 5.6 Configuration Parameters

Required Configuration Parameters (CP) are:

Item	Parameter	Reference	Allowed Values	Support
Sa 100	Configuration of own ETCS-Identity	[20] 7.2.4.2, 7.3.2.2		Yes
Sa 101A	Configuration of own ETCS-ID type	[20] 7.2.4.2	{RBC}	Yes
В			{Engine}	Yes
С			{Key manage- ment entity}	Yes No
Sa 102	Configuration of KMACs	[20] 7.2.2.2.4.4	168 Bit length	Yes
Sa 103	Configuration of timer T <sub>estab</sub>	[20] 7.3.2.3	40s	Yes
Sa 104	Configuration of safety feature	[20] 7.2.3.2.6, 7.2.4.2	{1}	Yes

**Table 5.14 - Configuration parameters** 



# 6. COMMUNICATION SERVICES AND PROTOCOLS

# 6.1 Communications Services Conformance Requirements

Item	Service	References	Status	Support
CoS1	Connection set up	[20] 8.1.2	М	Yes
CoS2	Normal data transfer	[20] 8.1.3	М	Yes
CoS3	Connection release	[20] 8.1.4	М	Yes
CoS4	High priority data transfer	[20] 8.1.5	М	Yes

Table 6.1 - Communication services conformance requirements

# 6.2 Supported Service Primitives

Testing of this non mandatory interface is optional

Item	Service Primitives	References	Status	Support
CoSP1	T-CONNECT.request	[20] B.1	0	Yes No
CoSP2	T-CONNECT.indication	[20] B.1	0	Yes No
CoSP3	T-CONNECT.response	[20] B.1	0	Yes No
CoSP4	T-CONNECT.confirm	[20] B.1	0	Yes No
CoSP5	T-DATA.request	[20] B.2	0	Yes No
CoSP6	T-DATA.indication	[20] B.2	0	Yes No
CoSP7	T-HP-DATA.request	[20] B.3	0	Yes No
CoSP8	T-HP-DATA.indication	[20] B.3	0	Yes No
CoSP9	T-DISCONNECT.request	[20] B.4	0	Yes No
CoSP10	T-DISCONNECT.indication	[20] B.4	0	Yes No
CoSP11	T-REGISTRATION.request	[20] B.5	0	Yes No
CoSP12	T-REGISTRATION.indication	[20] B.5	0	Yes No

Table 6.2 – Supported services primitives

# 6.3 Supported Parameters of Service Primitives

Testing of this non mandatory interface is optional

This section describes the parameters of the different service primitives of the Euroradio communications layer.



# 6.3.1 Connection Request

Item	Parameters	References	Status	Support
CoCRQ1	Called address:	[20] B.1	CoSP1:M	Yes
	Address type			
	Network address			
	Mobile Network ID			
	Called ETCS-ID and ETCS-ID type			
CoCRQ2	Calling address:	[20] B.1	CoSP1:M	Yes
	Calling ETCS-ID and ETCS-ID type			
CoCRQ3	Application Type	[20] B.1	CoSP1:M	Yes
CoCRQ4	QoS	[20] B.1	CoSP1:M	Yes
CoCRQ5	User data	[20] B.1	CoSP1:M	Yes

Table 6.3 - Connection request

## 6.3.2 Connection Indication

Item	Parameters	References	Status	Support
CoCl1	Called address:	[20] B.1	CoSP2:M	Yes
	Called ETCS-ID and ETCS-ID type			
CoCl2	Calling address:	[20] B.1	CoSP2:M	Yes
	Calling ETCS-ID and ETCS-ID type			
CoCl3	Application Type	[20] B.1	CoSP2:M	Yes
CoCl5	User data	[20] B.1	CoSP2:M	Yes

Table 6.4 - Connection Indication

# 6.3.3 Connection Response

Item	Parameters	References	Status	Support
CoCRP1	Responding address	[20] B.1	CoSP3:M	Yes
CoCRP2	User data	[20] B.1	CoSP3:M	Yes

**Table 6.5 – Connection Response** 



## 6.3.4 Connection Confirmation

Item	Parameters	References	Status	Support
CoCC1	Responding address	[20] B.1	CoSP4:M	Yes
CoCC2	User data	[20] B.1	CoSP4:M	Yes

#### **Table 6.6 – Connection Confirmation**

## 6.3.5 Data Request

Item	Parameters	References	Status	Support
CoDTR1	User data	[20] B.2	CoSP5:M	Yes

## Table 6.7 - Data Request

#### 6.3.6 Data Indication

Item	Parameters	References	Status	Support
CoDTI1	User data	[20] B.2	CoSP6:M	Yes

#### Table 6.8 – Data Indication

## 6.3.7 HP Data Request

Item	Parameters	References	Status	Support
CoHDR1	User data	[20] B.3	CoSP7:M	Yes

## Table 6.9 – HP Data Request

## 6.3.8 HP Data Indication

Item	Parameters	References	Status	Support
CoHDI1	User data	[20] B.3	CoSP8:M	Yes

## Table 6.10 - HP Data Indication

## 6.3.9 Disconnection Request

Item	Parameters	References	Status	Support
CoDISR1	User data	[20] B.4	CoSP9:M	Yes

# **Table 6.11 – Disconnection Request**



#### 6.3.10 Disconnection Indication

Item	Parameters	References	Status	Support
CoDISI1	Reason	[20] B.4	CoSP10:	Yes
			M	
CoDISI3	User data	[20] B.4	CoSP10:	Yes
			M	

Table 6.12 - Disconnection Indication

# 6.4 Transport Protocol Conformance Requirements

Note that the conformance requirements of the transport protocol are a subset of X.224 [17].

# 6.4.1 Protocol capabilities

Each question in this section refers to a major function of the protocol or the special cases of procedures elements which require clarification.

Item	Function	References	Status	Support
C2	Class 2	[17] 14	М	Yes

#### Table 6.13 - Classes implemented

Item	Function	References	Status	Support
IR1	Initiating CR TPDU	[17] 14.4 a)	М	Yes
IR2	Responding to CR TPDU	[17] 14.4 a)	М	Yes

#### Table 6.14 - Initiator/responder capability

Item	Function	References	Status	Support
T2F1	Assignment to network connection when operating over CONS	[17] 6.1.1	M	Yes
T2F2	TPDU transfer	[17] 6.2	М	Yes
T2F3	Segmenting	[17] 6.3	М	Yes
T2F4	Reassembling	[17] 6.3	М	Yes
T2F5	Concatenation	[17] 6.4	N/A	No
T2F6	Separation	[17] 6.4	N/A	No
T2F7	Connection establishment	[17] 6.5	М	Yes
T2F8	Connection refusal	[17] 6.6	М	Yes
T2F9	Normal release when operating over CONS (explicit)	[17] 6.7.1	М	Yes



Item	Function	References	Status	Support
T2F10	Error release when operating over CONS	[17] 6.8	M	Yes
T2F11	Association of TPDUs with Transport connections when operating over CONS	[17] 6.9.1	М	Yes
T2F12	Data TPDU numbering (normal)	[17] 6.10	M	Yes
T2F13	Data TPDU numbering (extended)	[17] 6.10	N/A	No
T2F14	Expedited data transfer when operating over CONS (Network normal)	[17] 6.11.1	N/A	No
T2F15	Reassignment after failure	[17] 6.12	N/A	No
T2F16	Retention and acknowledge TPDU	[17] 6.13	N/A	No
T2F17	Re-synchronization	[17] 6.14	N/A	No
T2F18	Multiplexing when operating over CONS	[17] 6.15	0	Yes NO
T2F19	De-multiplexing when operating over CONS	[17] 6.15	0	Yes NO
T2F20	Explicit flow control	[17] 6.16	M	Yes
T2F21	Checksum	[17] 6.17	N/A	No
T2F22	Frozen references	[17] 6.18	N/A	No
T2F23	Re transmission on time out	[17] 6.19	N/A	No
T2F24	Re-sequencing	[17] 6.20	N/A	No
T2F25	Inactivity control	[17] 6.21	N/A	No
T2F26	Treatment of protocol errors when operating over CONS	[17] 6.22.1	М	Yes
T2F27	Splitting	[17] 6.23	N/A	No
T2F28	Recombining	[17] 6.23	N/A	No

Table 6.15 - Supported functions

#### 6.4.2 Protocol data units

Indicating support for an item in this section states that the implementation has the capability to support the Protocol Data Units (PDUs).

The following TPDUs and the parameters which constitute their fixed parts are mandatory if a corresponding predicate in the status column is true.

Item	TPDU	TPDUs		Status	Support
ST1	CR	supported on transmission	[17] 13.1	М	Yes
ST2	CR	supported on receipt	[17] 13.1	М	Yes
ST3	CC	supported on transmission	[17] 13.1	М	Yes



Item	TPDU	s	References	Status	Support
ST4	CC	supported on receipt	[17] 13.1	М	Yes
ST5	DR	supported on transmission	[17] 13.1	М	Yes
ST6	DR	supported on receipt	[17] 13.1	М	Yes
ST7	DC	supported on transmission	[17] 13.1	М	Yes
ST8	DC	supported on receipt	[17] 13.1	М	Yes
ST9	DT	supported on transmission	[17] 13.1	М	Yes
ST10	DT	supported on receipt	[17] 13.1	М	Yes
ST11	AK	supported on transmission	[17] 13.1	М	Yes
ST12	AK	supported on receipt	[17] 13.1	М	Yes
ST13	ER	supported on receipt	[17] 13.1	М	Yes
ST14	ER	supported on transmission	[17] 13.1	0	Yes No

# Table 6.16 - Supported TPDUs

Supported parameters of issued TPDUs (variable part)

Item	Supported parameters	References	Status	Support	
I2CR6	Called Transport-Selector	[17] 13.3.4a)	М	Yes	
		[20] 8.2.4.6	M	Yes	
I2CR7	Calling Transport-Selector	[17] 13.3.4a)	М	Yes	
		[20] 8.2.4.6	M	Yes	
I2CR8	TPDU size	[17] 13.3.4b)	0	Yes No	
I2CR17	Preferred maximum TPDU size	[17] 13.3.4c)	0	Yes No	
I2CR12	Throughput	[17] 13.3.4 j)	0	Yes No	
I2CR13	Priority	[17] 13.3.4 l)	M	Yes	
I2CR14	Transit delay	[17]13.3.4m)	0	Yes No	

## Table 6.17 – Supported parameters of issued CR TPDU (ST1:)

Item	Supported parameters	References	Status	Support
I2CC6	Responding Transport-Selector	[17] 13.4.4	М	Yes
		[20] 8.2.4.6	M	Yes
I2CC7	Calling Transport-Selector	[17] 13.4.4	М	Yes
		[20] 8.2.4.6	M	Yes
I2CC8	TPDU size	[17] 13.4.4	0	Yes No
I2CC9	Throughput	[17] 13.4.4	0	Yes No
I2CC10	Priority	[17] 13.4.4	0	Yes No
I2CC11	Transit delay	[17] 13.4.4	0	Yes No



Item	Supported parameters	References	Status	Supp	ort
I2CC12	Preferred maximum TPDU size	[17] 13.4.4	0	Yes	No
		[17] 6.5.4 k)			

# Table 6.18 – Supported parameters of issued CC TPDU (ST3:)

Item	Supported parameter	References	Status	Support
I2DR4	Additional information	[17]13.5.4 a)	0	Yes No

# Table 6.19 – Supported parameters of issued DR TPDU (ST5:)

Item	Supported parameter	References	Status	Supp	ort
I2ER3	Invalid TPDU	[17]13.12.4 a)	0	Yes	No

## Table 6.20 – Supported parameters of issued ER TPDU (ST14:)

Supported parameters for received TPDUs

Implementers should be aware that implementations shall be capable of receiving and processing all possible parameters for all possible TPDUs, dependent upon the class and optional functions implemented.

#### User data in issued TPDUs

Item	User data	References	Status	Support
D2ICR	User data of up to 32 octets in a CR with preferred class 2	[17] 13.3.5	М	Yes
D2ICC	User data of up to 32 octets in a CC	[17] 13.4.5	М	Yes
D2IDR	User data of up to 64 octets in a DR	[17] 13.5.5	М	Yes

#### Table 6.21 - User data in issued TPDUs

#### User data in received TPDUs

Item	User data	References	Status	Support
DRCC	Up to 32 octets of user data in a CC TPDU	[17] 13.4.5	М	Yes
DRDR	Up to 64 octets of user data in a DR TPDU	[17] 13.5.5	М	Yes
DRCR	Up to 32 octets of user data in a CR TPDU	[17] 13.3.5	М	Yes

#### Table 6.22 - User data in received TPDUs

## 6.4.3 Negotiation

Item	Preferred class	References	Allowed values	Supported values
				values



Item	Preferred class	References	Allowed values	Supported values
NAC2	Alternative class parameter if the preferred class is Class 2	[17] 6.5.4 h)	None	
RC2	What classes can you respond with if CR proposes only class 2?	′	2 or connection refused	

# Table 6.23 - Class negotiation

Item	TPDU size	References	Status	Support
TS1	If maximum TPDU size is proposed in a CR TPDU then the initiator shall support all TPDU sizes from 128 octets to the maximum proposed.		I2CR8:M	Yes

Note that the TPDU size is fixed at the minimum size of 128 octets.

## Table 6.24 – TPDU size negotiation

Item	TPDU size	References	Allowed values	Supported values
T2S1	What is the largest value of the maximum TPDU size parameter which may be sent in a CR TPDU with preferred class 2?	[17] 14.5 e)	128	
T2S2	What is the largest value of the maximum TPDU size parameter which may be sent in a CC TPDU when class 2 is selected?	[17] 14.5 e)	128	

#### Table 6.25 - TPDU size value

Item	Extended format	References	Allowed values	Supported values
NEF1	What formats can you propose in the CR TPDU in class 2?	[17] 6.5.4 l)	normal	
NEF4	What formats can you select in CC when extended has been proposed in CR in class 2?	[17] 6.5.4 l)	normal	

#### Table 6.26 - Use of extended format

Item	Explicit flow control	References	Allowed values	Supported
				values



Item	Explicit flow control	References	Allowed values	Supported values
NUF1	What proposals can you make in the CR?	[17] 6.5.4 o)	use	
NUF2	What proposals can you make in CC when non-use of explicit flow control has been proposed in CR?	[17] 6.5.4 o)	use	

Table 6.27 - Explicit flow control

## 6.4.4 Error handling

Item	Item	References	Allowed values	Supported values
PE2	Class 2 Error handling	[17] 6.22.1.3	ER, DR	

## Table 6.28 – Action on receipt of a protocol error

Note: the release of the network connection is requested only if the transport connection is the only one using this network connection.

Item	Event	References	Status	Support
RR1	A parameter not defined in [17] or [20] section 8.2.4 & 8.2.5 shall be ignored	[17] 13.2.3	M	Yes
RR2	An invalid value in the alternative protocol class parameter shall be treated as a protocol error	[17] 13.2.3	M	Yes
RR3	An invalid value in the class and option parameter shall be treated as a protocol error	[17] 13.2.3	M	Yes
RR4	On receipt of the additional option selection parameter bits 8 to 5, and bits 4 to 1 if not meaningful for the proposed class shall be ignored.	[17] 13.3.4	М	Yes
RR6	On receipt of the class and option parameter bits 4 to 1 if not meaningful for the proposed class shall be ignored	[17] 13.3.3	М	Yes

## Table 6.29 – Action on receipt of an invalid or undefined parameter in a CR TPDU

Item	Event	References	Allowed actions	Supported
				actions



Item	Event	References	Allowed actions	Supported actions
RR7	A parameter defined in [17] or [20] section 8.2.4 & 8.2.5 (other than those covered above) and have an invalid value		Ignore, protocol error	

#### Table 6.30 - Action on receipt of a CR TPDU parameter with invalid value

Item	Event	References	Status	Support
UI1	A parameter not defined in [17] or [20] section 8.2.4 8.2.5 shall be treated as a protocol error	[17] 13.2.3	M	Yes
UI2	A parameter which has an invalid value as defined in [17]   [20] section 8.2.4 & 8.2.5 shall be treated as a protocol error		M	Yes

Table 6.31 - Actions on receipt of an invalid or undefined parameter in another TPDUs

### 6.4.5 Configuration parameters

Item	Event	References	Status	Support
ОТ3	Does IUT support optional timer <i>TS1</i> when operating in class 2?	[17] 6.5.4	0	Yes No
OT7	Does IUT support optional timer <i>TS2</i> when operating in class 2?	[17] 6.7.1.5	0	Yes No

#### Table 6.32 - Optional timers

Item	Event	References	Allowed values	Supported values
OT11	Standard TPDU length N <sub>TPDU</sub>	[20] 8.3	128 octets	
OT12	Initial credit of normal priority TPDUs	[20] 8.3	15	
OT13	Initial credit of low priority TPDUs	[20] 8.3	1	
OT14	Timer TS1	[17] 6.5.4	OT3:Tunable	
OT15	Timer TS2	[17] 6.5.4	OT7:Tunable	

Table 6.33 - Configuration parameter values



# 6.5 Network Protocol Conformance Requirements

### 6.5.1 Co-ordinating Function

Item	Function	References	Status	Support
CO1	Initiating B/B <sub>m</sub> channel establishment (outgoing calls)	[20] 8.2.3.1	M	Yes
CO2	Initiating B/B <sub>m</sub> channel establishment with eMLPP priority	[20] 8.2.3.1	0	Yes No
CO3	Responding to B/B <sub>m</sub> channel establishment (incoming calls)	[20] 8.2.3.1	М	Yes
CO4	Mapping of D/D <sub>m</sub> channel signalling causes into network service disconnect reasons	[20] 8.2.3.1	M	Yes
CO5	Request the disconnection of the data link of the $B/B_m$ channel before disconnecting the $B/B_m$ channel	[20] 8.2.3.1	M	Yes
CO6	Mapping of QoS parameters into bearer capability parameters	[20] 8.2.3.1	М	Yes
CO7	Indication of network originated of B/B <sub>m</sub> channel disconnection	[20] 8.2.3.1	М	Yes
CO8	Disconnect of data link layer followed by release of physical connection in case of disconnect phase	[20] 8.2.3.1.2	M	Yes

#### Table 6.34 – Co-ordinating function

The  $D/D_m$  channel protocol conformance requirements are specified in Annex A and section 5, respectively.

#### 6.5.2 B/Bm channel network layer

Item	Function	References	Status	Support
N1	Segmenting	[20] 8.2.3.2	М	Yes
N2	Reassembling	[20] 8.2.3.2	М	Yes

#### Table 6.35 - Protocol capabilities

Item	Parameter	References	Allowed values	Supported
				values
N3	Segment length N <sub>L3seg</sub>		N <sub>L3seg</sub> =(N1/8)-5	

Note:  $N_{L3seg}$  is related to the layer 2 frame length N1



Table 6.36 - Configuration parameter values

# 6.6 Data Link Protocol Conformance Requirements

### 6.6.1 Protocol capabilities

Each question in this section refers to a major function of the data link protocol HDLC.

Item	Function	References	Status	Support
Ls	Single link procedure	[13] 1 [20] 8.2.2.7a)	М	Yes
Lc	DTE/DCE Operation	[20] 8.2.2	N/A	No
Lt	DTE/DTE Operation	[20] 8.2.2.2	M	Yes
Lta	Assignment of A/B addresses as specified for a DCE	[20] 8.2.2.7i)	M	Yes
Lf	Frames structure	[11]	М	Yes

### Table 6.37 - Major capabilities

Item	Function	References	Status	Support
PC1	Asynchronous balanced mode (ABM)	[12] 5.1.3	M	Yes
PC2	Does the IUT support automatic negotiation of data link layer parameters?	[12]	N/A	No
PC3	Does the IUT support internal parameter initialisation?	[12]	N/A	No

#### Table 6.38 - Supported functions

Item	Option	References	Status	Support
OP1	Exchange identification (XID)	[14] Table1	N/A	No
OP2	Reject (REJ)	[14] Table1	N/A	No
OP3.1	Selective reject (SREJ)	[14] Table1 [20] 8.2.2	N/A	No
OP3.2	Multi-selective reject (SREJ)	[14] Table1 [20] 8.2.2	М	Yes
OP4	Unnumbered information (UI)	[14] Table1 [20] 8.2.2	M	Yes
OP5	Initialisation of remote data station (SIM RIM)	[14] Table1	N/A	No
OP6	Unnumbered polling (UP)	[14] Table1	N/A	No
OP7	Extended addresses	[14] Table1	N/A	No



Item	Option	References	Status	Support
OP8	I frames as command only	[14] Table1	N/A	No
OP9	I frames as response only	[14] Table1	N/A	No
OP10	Extended (modulo 128) operation (SABME)	[14] Table1	М	Yes
(M128)		[20] 8.2.2		
OP11	Reset of state variables (RSET)	[14] Table1	N/A	No
OP12	Data link test (TEST)	[14] Table1	N/A	No
OP13	Request of disconnection (RD)	[14] Table1	N/A	No
OP14a	32 bit frame check sequence (FCS32)	[14] Table1	N/A	No
OP14b	16 bit frame check sequence (FCS16)	[14] Table1	М	Yes
OP15.1	Start/stop transmission	[14] Table1	M	Yes
		[20] 8.2.2		

### Table 6.39 - Options

Item	Function	References	Status	Support
LSI1	Initiation of link setup	[13] 5.3.1	М	Yes
LSI2	If initiation of link setup is supported, does the DTE initiate link disconnection before initiating link setup	[13] 5.3.1	LSI1:O	Yes No
LSI3	Initiation of link setup on receiving an unsolicited DM response	[13] 4.3.8, [13] 5.5	N/A	No
LSA	Response to link setup attempts by acceptance, and entry into the information transfer phase	[13] 5.3.1	M	Yes
LSD	Denial of link setup attempts by the DCE/remote DTE, i.e by transmission of DM response)	[13] 5.3.1	0	Yes No
LSR	Transmission of unsolicited DM response to request the remote DTE to initiate link setup	[20] 8.2.2	N/A	No
LS	Initiation of link setup by the DCE	[20] 8.2.2.7.j	N/A	No

Table 6.40 - Link setup



Item	Function	References	Status	Support
LD1	Initiation of link disconnection	[13] 5.3.3	М	Yes
LD2	Response to link disconnection by the DCE/remote DTE	[13] 5.3.3	M	Yes
LD3	Link disconnection because out of service condition	[13] 5.3.3	M	Yes
LDP	Response to DISC commands, and to other commands with P=1, received during the disconnected phase	[13] 5.3.3	M	Yes

Table 6.41 - Link disconnection

#### 6.6.2 Frames/Protocol data units

Indicating support for an item in this section states that the implementation has the capability to support the frames that may be exist. The support of a received frame implies the parsing of all fields of the frame.

Item	Frame ty	ре	References	Status	Support
FT1	I	supported as command	[13] 4.3.1	М	Yes
FT2a	I	supported as response with F=1	[13] 4.3.1	М	Yes
			[20] 8.2.2.9		
FT2b	I	supported as response with F=0	[20] 8.2.2.9	N/A	No
FT3	RR	supported as command	[13] 4.3.2	М	Yes
FT4	RR	supported as response	[13] 4.3.2	М	Yes
FT5	RNR	supported as command	[13] 4.3.3	М	Yes
FT6	RNR	supported as response	[13] 4.3.3	М	Yes
FT7	SABME	supported as command	[13] 4.3.5	М	Yes
FT8	DM	supported as response	[13] 4.3.8	М	Yes
FT9	DISC	supported as command	[13] 4.3.6	М	Yes
FT10	FRMR	supported as response	[13] 4.3.9	М	Yes
FT11	UA	supported as response	[13] 4.3.7	М	Yes
FT12	SREJ	supported as command	[12] 7.2.4	N/A	No
			[20] 8.2.2.10		
FT13	SREJ	supported as response	[12] 7.2.4	М	Yes
FT14	UI	supported as command	[12] 7.3.1.10	М	Yes
FT15	UI	supported as response	[12] 7.3.1.10	М	Yes



### Table 6.42 - Supported frame types

Item	Supported fields	References	Status	Supp	ort
F1a	Sending of non-octet aligned frames	[13] 3.4	N/A	No	)
	Support of the specific frame structure	[13] 3,			
F2a	- Opening flag	table 2	М	Ye	S
F2b	- Address		М	Ye	S
F2c	- Control		М	Ye	S
F2d	- FCS		М	Ye	S
F2e	- Closing flag		М	Ye	S
F3	Acceptance of a single flag as both the closing flag for one frame and the opening flag of the next frame	[13] 3.1	М	Ye	S
F4	Generation of a single flag as above	[13] 3.1	0	Yes	No
FA	Frame abortion for transmitted frames	[13] 3.9	0	Yes	No
F6	One octet address field	[13] 3.2	М	Ye	S
F7	Two octet control field	[13] 4.1	FT1 to FT6: M FT 12 and FT 13: M	Ye	S
F8	One octet control field of unnumbered frames	[13] 4.1	FT7 to FT 11: M FT14 and FT15: M	Ye	S
F9	Ascending numerical order of bit transmission?	[13] 3.7	М	Ye	S
F10	User data field	[13]	FT1, FT2, FT14, FT 15: M FT12, FT 13: O	Ye	S

Table 6.43 - Frame structure



Item	Supported fields	References	Status	Support
F5	Interframe time fill (start/stop transmission)	[12] 4.1.3.2		
	- by flags	[20] 8.2.2.7 I)	N/A	No
	- by mark condition (logical "1")		M	Yes

Table 6.44 - Interframe fill

#### 6.6.3 Information transfer

Item	Protocol feature	References	Status	Support
IT	Transmission of I frames	[13] 5.4.1, [13] 5.4.5	М	Yes
ITs	Processing of send sequence numbers in transmitted N(S) and received N(R) values	[13]	M	Yes
	Checkpoint recovery, initiated by transmitting:	[13] 4.4.2.1		
ITCi	- I frames with P=1		0.6	Yes No
ITCs	- Supervisory frames with P=1		0.6	Yes No
ITB	Stopping transmission of I frames on receipt of RNR frames	[13] 4.4.1, [13] 5.4.7	М	Yes
IR	Reception of I frames	[13] 5.4.2	M	Yes
IRs	Processing of receive sequence numbers in received N(S) and transmitted N(R) values	[13]	М	Yes
IRRJ	Initiation of REJ recovery on receipt of out-of- sequence I frames	[13] 4.4.2.2, [13] 5.4.4	N/A	No
IRSRJ	Initiation of SREJ recovery on receipt of out-of- sequence I frames	[12] 8.2.3	М	Yes
IRB	DTE busy condition	[13] 4.4.1, [13] 5.4.8	M	Yes
IHP	UI frames transmission with highest priority	[20] 8.2.2	М	Yes

Table 6.45 – Information transfer



### 6.6.4 Error handling

Item	Protocol feature	References	Status	Support
	Initiation of link reset	[13] 5.6.1		
LRIa	- on receipt of FRMR	[20] 8.2.2	N/A	No
LRIb	- on receipt of unsolicited UA	[20] 8.2.2, [13] 5.5, [13] 5.6.1	N/A	No
LRIc	- on receipt of unsolicited F=1	[13] 5.5, [13] 5.6.1	0	Yes No
LRId	- otherwise	[13] 5.6.1	0	Yes No
	Initiation of remote link reset, by transmission			
	of DM response during information transfer			
LRRa	phase	[20] 8.2.2	N/A	No
LRRb	- on receipt of FRMR	[20] 8.2.2,	N/A	No
	- on receipt of unsolicited UA	[13] 5.5, [13] 5.6.1		
LRRc			N/A	No
	- on receipt of unsolicited F=1	[13] 5.5, [13] 5.6.1	N1/A	
		[20] AnnexD	N/A	No
LRRd		[13] 5.6.1		
	- otherwise	[20] AnnexD		
LRA	Acceptance of link reset attempts by the	[13] 5.6.1	N/A	No
	DCE/remote DTE	[20] AnnexD		
LRD	Denial of link reset attempts by the	[13] 5.6.1	N/A	No
	DCE/remote DTE (i.e. by transmission of DM response)	[20] AnnexD		
	Resolution of collision of unnumbered commands that are the same by entering the indicated phase	[13] 5.3.5		
LCRa	- after receiving the UA_RSP		O.5	Yes No
LCRb	- after sending the UA_RSP		O.5	Yes No
LCRc	- after timing out waiting for UA_RSP having sent UA_RSP		O.5	Yes No
LCRd	Resolution of collision of different unnumbered commands	[13] 5.3.5	М	Yes



Table 6.46 – Action on receipt of a protocol error

Item	Protocol feature	References	Status	Support
FR1	Entry to frame rejection condition on receipt, during information transfer phase, of a frame containing one of the error conditions:  - On receiving an undefined frame	[13] 4.4.4, [13] 4.3.9, [13] 5.5	М	Yes
	- On receiving a supervisory or unnumbered frame with incorrect length			
	- On receiving an invalid sequential number N(R)			
	- On receiving a frame with an information field exceeding N1 (maximum number of bits)			
FR2	Full support of the frame rejection condition	[13] 5.6.2	М	Yes
F1b	Discard of non-octet aligned frames as invalid	[13] 3.8, [13] 5.4.3	M	Yes
FD	Recognition and discarding of all invalid frames	[13] 3.8, [13] 4.4.3	M	Yes
FR3	The two octet sequence 'control-escape - closing flag' interpreted as abort and the associated frame ignored	[13] 3.9	M	Yes

Table 6.47 - Actions on receipt of an invalid frame

Item	Protocol timer function	References	Status	Support
	Does the DTE support timer T1 recovery for the following frames sent:			
T1a	- I frames	[13] 5.4.1, [13] 5.4.5, [13] 5.4.9	M	Yes
T1b	- SABME	[13] 5.3.1	M	Yes
T1c	- DISC	[13] 5.3.3	0	Yes No
T1d	- FRMR	[13] 5.6.2	0	Yes No
T1e	- Supervisory frame with P=1	[13] 5.4.9	M	Yes
T1f	- unsolicited DM with F=0	[13] 5.3.4	N/A	No
N2a	Does the DTE indicate failure to a higher layer after N2 attempts to send DISC?	[13] 5.3.4	M	Yes
N2b	Does the DTE indicate failure to a higher layer after N2 attempts to send SABM/SABME?	[13] 5.3.1, [13] 5.6.1	M	Yes



Item	Protocol timer function	References	Status	Support
	Does the DTE support the following timer procedures:			
Т3	- Timer T3 procedure	[13] 3.11.2, [13] 5.7.1.3	0	Yes No
T4	- Timer T4 procedure	[13] 5.3.2, [13] 5.6.1	0	Yes No

Table 6.48 – Actions on timing out

### 6.6.5 Configuration Management

Item	Parameter	References	Status	Allowed values	Supporte d values
SPT1	Acknowledge time (T1)	[13] 5.7.1.1	M	0.8 - 2 s	a raidee
<u> </u>	/ total of the day of the control of	[10] 011111	IVI	0.0 2 0	
SPT2	Local processing delay time (T2)	[13] 5.7.1.2	M	< 80 ms	
SPT3	Out of service time (T3)	[13] 5.7.1.3	T3:M		
SPT4	Inactivity time (T4)	[13] 5.7.1.4,	T4:M		
		[13] 5.3.2			
SPN1	Maximum number of bits in a I	[13] 5.7.3	M	240 - 1024	
	frame (N1)				
SPN2	Maximum number of attempts to	[13] 5.7.2	M	3 – 6	
	complete transmission (N2)				
SPk	Maximum number of outstanding	[13] 5.7.4	М	9 – 61	
	I frames (k)				
SPA	Address (according to DTE/DCE	[13] 1.5.1	М	A,B	
	role)				

**Table 6.49 – Configuration parameters** 



# 6.7 Management conformance requirements

Item	Function	References	Status	Support
MA1a	Mapping ETCS-ID <-> TSAP address	[20] 8.3.1	M	Yes
MA2	Configuration management	[20] 8.3.2	0	Yes No
MA2a	Different sets of configuration parameters	[20] 8.3.2	MA2: O	Yes No
MA2c	Changing configuration parameters	[20] 8.3.2	MA2: O	Yes No
MA3	Error logging	[20] 8.3.3	0	Yes No
MA4	Error reporting by T-DISC.ind primitive	[20] 8.3.3	M	Yes

Table 6.50 - Communication management



### ANNEX A: INTERFACE TO MOBILE TERMINAL

#### A.1 Introduction

This section includes the PICS for the interface to Mobile Terminal. The reference column refers to the corresponding section of FFFIS for EuroRadio [23].

Radio Transmission FFFIS for EuroRadio [23] provides a specification of the interface between the GSM-R Mobile Terminal and the on-board Terminal Equipment.

The use of MT2 Mobile Terminal is recommended when interchangeability at the interface is required.

MT2 Mobile Terminal type and interface are defined in GSM 07.01 [19] together with the physical properties in GSM 07.02 [24] / 07.03 [25] and the functional properties in GSM 07.07 [26]. This fixes the so-called V-interface at the R reference point.

The following conformance requirements in this Annex A have to be applied on the V-interface at R reference point, for the Terminal Equipment.




Figure A1: Interface between on-board Terminal and MT2 mobile Terminal

© This document has been developed and released by UNISIG



# A.2 Physical Interface Conformance Requirements

### A.2.1 Supported signals

Item	Function	Reference s	Status	Support
MC1	Circuit 102 (Common Return)	[23] 4.2.1	М	Yes
MC2	Circuit 103 (TxD – Transmitted Data)	[23] 4.2.1	M	Yes
MC3	Circuit 104 (RxD – Received Data)	[23] 4.2.1	M	Yes
MC4	Circuit 105 (RTS – Request to Send)	[23] 4.2.1	M	Yes
MC5	Circuit 106 (CTS – Clear to Send)	[23] 4.2.1	М	Yes
MC9	Circuit 107 (DSR – Data Set Ready)	[23] 4.2.1	0	Yes No
MC6	Circuit 108/2 (DTR – Data Terminal Ready)	[23] 4.2.1	M	Yes
MC7	Circuit 109 (DCD – Data Carrier Detect)	[23] 4.2.1	M	Yes
MC8	Circuit 125 (RI – Ring Indicator)	[23] 4.2.1	0	Yes No

Table A1 - Supported signals

# A.3 Functional Interface Conformance Requirements

### A.3.1 Supported functional properties

Item	Function	Reference s	Status	Support
MC11	Compliance with ITU-T V.25ter (sections 5.1, 5.2, 5.3, 5.4, 5.5, 5.6, 5.7)	[23] 4.4.2	М	Yes
MC12	Result codes	[23] 4.4.4	М	Yes
MC13	(Enable/disable manufacturer-specific escape sequence)	[23] 4.4.3	М	Yes
MC14	Select Bearer Service Type	[23] 4.4.5.1	М	Yes
MC15	Dial Command	[23] 4.4.5.2	М	Yes
MC16	Select priority level	[23] 4.4.5.3	М	Yes



Item	Function	Reference s	Status	Support
MC17	Answer	[23] 4.4.6.5	М	Yes
MC18	Call Clearing	[23] 4.4.7	М	Yes
MC20	Echo de(activation)	[23] 4.4.8.1	М	Yes
MC21	Reset to default configuration	[23] 4.4.9.1	М	Yes
MC22	Set to factory-defined configuration	[23] 4.4.9.2	0	Yes No
MC23	Operator selection	[23] 4.4.10.3	М	Yes
MC24	Phone activity status	[23] 4.4.11.1	0	Yes No
MC26	Signal quality	[23] 4.4.11.2	0	Yes No
MC28	Sets the number of call indication rings	[23] 4.4.6.1	0	Yes No
MC29	Circuit 109 behaviour	[23] 4.4.3.	М	Yes
MC30	Circuit 108/2 behaviour	[23] 4.4.3.	М	Yes

Table A2 - Supported functional properties



### ANNEX B: INTERFACE TO FIXED NETWORK

### **B.1** Introduction

This section includes the PICS for the interface to the fixed network, when ISDN PRI ( $S_{2M}$ ) is used. The reference column refers to the corresponding section of FFFIS for EuroRadio [23].

Radio Transmission FFFIS for EuroRadio [23] provides a specification of the requirements for the interface between the fixed network and the trackside RBC.

According to this specification the use of ISDN PRI (Primary Rate Interface) is recommended.

The following conformance requirements in this Annex B have to be applied on the  $I_{fix}$  interface, for the trackside Terminal Equipment.

### **B.2** ISDN conformance requirements

Item	Access	Reference	Status	Support
FC1	Layer 1 access protocol conform to ETS 300 011 for primary rate interface	[23] 3.3	М	Yes
FC2	Layer 2 access protocol conform to ETS 300 125	[23] 3.3	М	Yes
FC3	Layer 3 access protocol conform to ETS 300 102-1 or ETS 300 403-1	[23] 3.3	М	Yes
FC4	Bearer Capability attribute (UDI, circuit, 64 kbit/s)	[23] 3.3.4.2.1	М	Yes
FC5	Low Layer Compatibility	[23] 3.3.4.2.1	М	Yes

#### Table B1 - ISDN conformance requirements

ETS 300 156 [6] specifies the requirements which ISDN terminal equipment shall meet for attachment to the public ISDN primary rate user-network interface at the T, or coincident S and T, reference points. It specifies:

- Layer 1 shall be in accordance to ETS 300 011 [2];
- Layer 2 of the control plane shall be in accordance to ETS 300 125 [5];
- Layer 3 of the control plane shall be in accordance to ETS 300 102-1 [4] or ETS 300 403-1 [27];
- The EMC, electrical safety and protection shall be in accordance to ETS 300 046 [3].

© This document has been developed and released by UNISIG



ITU-T Rec. I.431 [15] is concerned with the layer 1 electrical, format and channel usage characteristics of the primary rate user-network interface at the S and T reference points.

ETS 300 011 [2] is based on ITU-T Rec. I.431 and gives further requirements or modifications to that Recommendation. It identifies for each clause of I.431 whether it is regarded as normative, informative or as not relevant in the sense of an ETS (e.g. the interface at 1544 kbit/s is not applied).

The conformance clause is contained in Annex C: Conformance test principles for the user and the network side of the interface. The SCS, PICS, and PIXIT proformas are contained in Annex F: System Conformance Statement (SCS), Protocol implementation Conformance Statement (PICS) and Protocol implementation eXtra Information for Testing (PIXIT) for interface Reference point  $I_a$  and  $I_b$ .

ISDN user-network layer 2, signalling protocols and associated conformance testing specifications are specified in ETS 300 125 [5]. ISDN user-network layer 3, signalling protocols and associated conformance testing specifications are specified in ETS 300 102 [4] or ETS 300 403-1 [27]. The corresponding proformas are specified in ETS 300 306 [7], ETS 300 310 [8], ETS 300 315 [9], and ETS 300 319 [10].

The connector is specified in ENV 41 001 [1].

### **B.3** Additional conformance requirements

Item	Access	Reference	Status	Support
FC6	V.110 rate adaptation in user channel	[23] 3.2.2	М	Yes

**Table B2 - Additional conformance requirements**