

ERTMS/ETCS
System Requirements Specification Chapter 8 Messages
REF : SUBSET-026-8 ISSUE : 4.0.0 DATE : 05/07/2023

8.1 Modification History

Issue Number Date	Section Number	Modification / Description	Author
0.0.1 990715	All	Creation of the document “Clean version” based on SRS Class P Ch. 8	V. Roger
0.0.2 990716	All	Update to SRS Class 1	V. Roger
0.1.0 990727	All	Update considering review comments from ADT and ALS	V. Roger
1.0.0 990729	Version number and editorial changes.	Finalisation meeting, Stuttgart 990729.	HE
1.2.0 990730	Version number	Release version	HE
1.2.1 991124	Sections 8.4 to 8.7	ECSAG comments (on chapter 8) taken into account.	V. Roger
1.2.2 991209	Sections 8.4 to 8.7. Creation of appendix.	Upsate to SRS Class 1 version 2 – First release	V. Roger
1.3.0 991217	Sections 8.4 to 8.7. Suppression of appendix.	Upsate to SRS Class 1 version 2 – Unisig Review (991216)	V. Roger
1.3.1 991220	Section 8.7.14	Add Q_SCALE	P. Rimbaud
2.0.0 991222	Minor editorial changes	Release version	Ch. Frerichs (ed.)
2.0.1 001002	All	Corrections after UNISIG review 15 June 00	P. Rimbaud
2.1.0 001026	Sections 8.4.1, 8.4.2, 8.4.3, 8.4.4, 8.5.1, 8.5.2, 8.5.3, 8.6, 8.7	Corrections after UNISIG review 10/11 October 00	P. Rimbaud
2.2.0	Packet 71 deleted, NID_C 10 bit	UNISIG release	SAB
2.2.2	Packet 71 added, messages 42 and 158 deleted	SUBSET-026 Corrected Paragraphs, Issue 2.2.2	JY. Riou
2.2.4 – 040512		UNISIG Change Request according the scope defined in the 06/05/2004 e-mail	JY. RIOU

ERA * UNISIG * EEIG ERTMS USERS GROUP

Issue Number Date	Section Number	Modification / Description	Author
2.2.4 SG checked 28/05/04		Including all CLRs agreed with EEIG (see “List of CLRs agreed with EEIG for SRS v2.2.4” dated 28/05/04) Affected clauses see change marks	H. Kast
2.2.5 21/01/05		Incorporation of solution proposal for CLR 007 with EEIG users group comments	A. Hougardy
2.2.6 04/02/05		§ 8.4.2.1, § 8.4.3.1, § 8.7.12 according to CR242 § 8.4.4.4.1.1, § 8.5.3, § 8.7.22 according to CR458 § 8.6.3 according to CR 487	JY. RIOU
2.2.7 01/08/05		§ 8.7.22 error correction (Q_ORIENTATION) according to CR458, § 8.4.4.4.2 according to CR 126 §8.4.4.4.3 b), § 8.6.17 according to CR 299 § 8.4.1.4.5, § 8.4.4.4.1 according to CR 413 § 8.4.1.4.6 according to CR 633	JY.RIOU
2.2.8 30/11/05		Change marks cleaned up and updated according to last CR decisions (including split of CRs 7 and 126)	JY. RIOU
2.2.9 24/02/06		Including all CR s that are classified as “IN” per Subset-108 version 1.0.0 Removal of all CRs that are not classified as “IN” as per SUBSET-108 version 1.0.0 with the exception of the CR 63, 98, 120, 158 and 538	JY. RIOU
2.3.0 24/02/06		Release version	HK
2.3.1 14/06/2006		§ 8.4.4.4.1 and § 8.7.5: “SRS v2.3.0 Release Note CR 382” point, § 8.4.4.4.3 b) and 8.6.17: removing of premature CR299 update	JY. RIOU
2.3.2 17/03/08		Including all CRs that are in state “Analysis completed” according to ERA CCM	A. Hougardy
2.9.1 06/10/08		Including all enhancement CR’s retained for 3.0.0 baseline and all other error CR’s that are in state “Analysis completed” according to ERA CCM For editorial reasons, the following CR’s are also included: CR656, CR804, CR821	A. Hougardy
3.0.0 23/12/08		Release version	A. Hougardy

ERA * UNISIG * EEIG ERTMS USERS GROUP

Issue Number Date	Section Number	Modification / Description	Author
3.0.1 22/12/09		Including the results of the editorial review of the SRS 3.0.0 and the other error CR's that are in state "Analysis completed" according to ERA CCM	A. Hougardy
3.1.0 22/02/10		Release version	A. Hougardy
3.1.1 08/11/10		Including all CR's that are in state "Analysis completed" according to ERA CCM, plus CR731.	A. Hougardy
3.2.0 22/12/10		Release version	A. Hougardy
3.2.1 13/12/11		Including all CR's that are in state "Analysis completed" according to ERA CCM	A. Hougardy
3.3.0 07/03/12		Baseline 3 release version	A. Hougardy
3.3.1 04/04/14		CR's 1155, 1185	O. Gemine
3.3.2 23/04/14		Baseline 3 1 st maintenance pre-release version	O. Gemine
3.3.3 06/05/14		CR 1223 Baseline 3 1 st maintenance 2 nd pre-release version	O. Gemine
3.4.0 12/05/14		CR 1223 Baseline 3 1 st maintenance release version	O. Gemine
3.4.1 23/06/15		CR's 1014, 1222	O. Gemine
3.4.2 17/11/15		CR's 299, 1262, 1265, 1266	O. Gemine
3.4.3 16/12/15		Update due to overall CR consolation phase	O. Gemine
3.5.0 18/12/15		Baseline 3 2 nd release version as recommended to EC (see ERA-REC-123-2015/REC)	O. Gemine
3.5.1 28/04/16		No change	O. Gemine
3.6.0 13/05/16		Baseline 3 2 nd release version	A. Hougardy
3.6.1 29/05/17		No change	O. Gemine

ERA * UNISIG * EEIG ERTMS USERS GROUP

Issue Number Date	Section Number	Modification / Description	Author
3.6.2 31/05/18	No change		O. Gemine
3.6.3 21/02/20	CR 1313		O. Gemine
3.6.4 22/06/20	No change		O. Gemine
3.6.5 22/12/21	CR 1238		O. Gemine
3.6.6 29/08/22	CR's 968, 1120, 1342, 1350, 1367, 1408		O. Gemine
3.9.1 24/11/22	CR's 988, 1307, 1423		O. Gemine
3.9.2 21/02/23	No change		O. Gemine
3.9.3 31/05/23	CR's 1306, 1359 Outcome of B4R1 3 rd consolidation phase		A Hougardy O. Gemine
3.9.4 30/06/23	CR 1342 (updated) Outcome of B4R1 4 th consolidation phase		A Hougardy O. Gemine
4.0.0 05/07/23	Baseline 4 1 st release version		A Hougardy O. Gemine

8.2 Table of Contents

8.1	Modification History.....	2
8.2	Table of Contents.....	6
8.3	Introduction	8
8.3.1	Scope and Purpose.....	8
8.3.2	Definitions	8
8.4	Rules.....	10
8.4.1	Common Rules	10
8.4.2	Rules for Eurobalise telegrams	12
8.4.3	Rules for Euroloop messages	13
8.4.4	Rules for Euroradio messages	14
8.5	List of radio Messages	18
8.5.1	Introduction	18
8.5.2	Train to Track radio messages.....	18
8.5.3	Track to Train radio messages.....	19
8.6	Definition of Radio Messages from Train to Track.....	20
8.6.1	Message 129: Validated Train Data	20
8.6.2	Message 130: Request for Shunting	20
8.6.2.1	Message 131: Request for Supervised Manoeuvre	20
8.6.3	Message 132: MA Request.....	21
8.6.3.1	Message 133: Safe consist length information for SM	21
8.6.4	Message 136: Train Position Report	21
8.6.5	Message 137: Request to Shorten MA is granted	22
8.6.6	Message 138: Request to Shorten MA is rejected.....	22
8.6.7	Message 146: Acknowledgement.....	22
8.6.8	Message 147: Acknowledgement of Emergency Stop.....	23
8.6.9	Message 149: Track Ahead Free Granted	23
8.6.10	Message 150: End of Mission	24
8.6.11	Message 153: Radio infill request	24
8.6.12	Message 154: No compatible version supported.....	24
8.6.13	Message 155: Initiation of a communication session.....	25
8.6.14	Message 156: Termination of a communication session	25
8.6.15	Message 157: SoM Position Report.....	25
8.6.16	Message 158: Text Message Acknowledged by Driver	26
8.6.17	Message 159: Session established	26
8.7	Definition of Radio Messages from Track to Train.....	27
8.7.1	Message 2: SR Authorisation.....	27
8.7.2	Message 3: Movement Authority	27

8.7.2.1	Message 4: SM Authorisation	28
8.7.2.2	Message 5: SM Refused	28
8.7.3	Message 6: Recognition of exit from TRIP mode	29
8.7.3.1	Message 7: Acknowledgment of safe consist length info for SM	29
8.7.4	Message 8: Acknowledgement of Train Data	29
8.7.5	Message 9: Request to Shorten MA	30
8.7.6	Message 15: Conditional Emergency Stop	30
8.7.7	Message 16: Unconditional Emergency Stop	31
8.7.8	Message 18: Revocation of Emergency Stop	31
8.7.9	Message 24: General message	31
8.7.10	Message 27: SH Refused	32
8.7.11	Message 28: SH Authorised	32
8.7.12	Message 32: RBC/RIU System Version	32
8.7.13	Message 33: MA with Shifted Location Reference	33
8.7.14	Message 34: Track Ahead Free Request	33
8.7.15	Message 37: Infill MA	34
8.7.16	Message 38: Acknowledgement of session establishment	34
8.7.17	Message 39: Acknowledgement of termination of a communication session	34
8.7.18	Message 40: Train Rejected	35
8.7.19	Message 41: Train Accepted	35
8.7.20	Intentionally deleted	35
8.7.21	Message 43: SoM position report confirmed by RBC	35
8.7.22	Message 45: Assignment of coordinate system	36


8.3 Introduction

8.3.1 Scope and Purpose

- 8.3.1.1 This chapter defines the format and content of messages necessary for ERTMS/ETCS functions.
- 8.3.1.2 Concerning the transmission media, this chapter does not cover considerations such as medium-specific use constraints (e.g. distance between track-circuit and balise...), as well as functions (e.g. detection of balise reference, time and location stamp, identifying type of receiving balise, Key Management, Releasing/maintaining a radio connection...) and performance of the transmission media.

8.3.2 Definitions

- 8.3.2.1 Transmission media considered hereafter are standard ERTMS/ETCS transmission media used for ETCS (Eurobalise, Euroradio and Euroloop).
- 8.3.2.2 A message includes user data (application level) and protocol data (depending on the transmission medium).
- 8.3.2.3 A Eurobalise message is the information sent by a balise group (i.e. the message is composed of one or several telegrams, sorted by balise number in the group (telegram from balise number 1 first), each telegram is transmitted by a Eurobalise). A Eurobalise telegram contains one header and an identified and coherent set of Packets.



Composition of message when passing the balise group in nominal direction:

Balise telegrams read:

1 st

2 nd

3 rd

Balise message composed:

1 st

2 nd

3 rd

Composition of message when passing the balise group in reverse direction:

Balise telegrams read:

3 rd

2 nd

1 st

Balise message composed:

1 st

2 nd

3 rd

Figure 1: Composition of a balise group message

- 8.3.2.4 A Euroradio message contains one header and an identified and coherent set of variables (if needed) and Packets.
- 8.3.2.5 A Euroloop message contains one header and an identified and coherent set of Packets.

8.4 Rules

8.4.1 Common Rules

- 8.4.1.1 A message (Euroradio/Euroloop) or telegram (Eurobalise) is composed of
1. One Header,
 2. When needed, a predefined set of variables (only for Radio),
 3. When needed, a predefined set of Packets (only for Radio),
 4. Optional Packets as needed by application.
- 8.4.1.2 The transmission order shall respect the order of data elements listed in the message format (from top to bottom).
- 8.4.1.3 The behaviour of the receiver shall not depend on the sequence of the Packets given by the message.
- 8.4.1.3.1 Exception for Infill information: The locations given in the packets following packet 136 (Infill Location Reference) shall be referred to the balise group indicated in such packet.
- 8.4.1.3.2 Note: orientations are in any case always referred to the directionality of balise group (balise transmission), directionality of loop (Euroloop transmission) or directionality of LRBG (radio transmission).
- 8.4.1.4 A track-to-train message shall contain at most one instance of the same packet type for the same direction.
- 8.4.1.4.1 Exception 1: A message can contain several packets 44 (Data used by applications outside the ERTMS/ETCS system).
- 8.4.1.4.2 Exception 2: A message can contain several packets 65 (Temporary Speed Restriction). In case of revocable TSRs, the identities of the corresponding temporary speed restrictions (variable NID_TSR) transmitted in the same message shall be different.
- 8.4.1.4.3 Exception 3: A message can contain several packets 66 (TSR Revocation). The identities of the corresponding temporary speed restrictions (variable NID_TSR) transmitted in the same message shall be different.
- 8.4.1.4.4 Exception 4: A message transmitted by a balise group can contain one packet 136 per balise telegram per direction. Each packet 136 indicates which part of that telegram is to be considered as part of the infill information. Multiple packets 136 in balises of a balise group shall have identical content per direction.
- 8.4.1.4.5 Exception 5: A message can contain several packets 88 (Level Crossing information). The identities of the corresponding Level Crossings (variable NID_LX) transmitted in the same message shall be different.

- 8.4.1.4.6 Exception 6: A message transmitted by a balise group can contain several packets 254 (default balise, loop or RIU information).
- 8.4.1.4.7 Exception 7: A message transmitted by a balise group can contain several packets 145 (Inhibition of balise group message consistency reaction).
- 8.4.1.4.8 Exception 8: A message transmitted by a balise group can contain several packets 0 (Virtual Balise Cover marker).
- 8.4.1.4.9 Exception 9: A message transmitted by a balise group can contain several packets 6 (Virtual Balise Cover order). The identities (pairs of variables NID_VBCMK and NID_C) of the corresponding VBC transmitted in the same message shall be different.
- 8.4.1.5 A train-to-track message shall contain at most one instance of the same packet type.
- 8.4.1.5.1 Exception: A message can contain several packets 44 (Data used by applications outside the ERTMS/ETCS system).
- 8.4.1.6 Note: For the purposes of clause 8.4.1.4, when the same packet is transmitted by duplicated balises, this is considered to be only a single instance of the packet within the message. Justification: The on-board equipment will only use one of these duplicated telegrams (and therefore only one set of duplicated packets) to compose the balise group message (see 3.16.2.4.8.2).

8.4.2 Rules for Eurobalise telegrams

8.4.2.1 The format of the telegram to be transmitted by each balise is as follows:

General Format of Balise Telegram			
Field No.	VARIABLE	Length (bits)	Remarks
1	Q_UPDOWN	1	Defines the direction of the information: Down-link telegram (train to track) (0) Up-link telegram (track to train) (1)
2	M_VERSION	7	Version of the ERTMS/ETCS system.
3	Q_MEDIA	1	Defines the type of media: Balise (0)
4	N_PIG	3	Position in the group. Defines the position of the balise in the balise group.
5	N_TOTAL	3	Total number of balises in the balise group
6	M_DUP	2	Used to indicate whether the information of the balise is a duplicate of the balise before or after this one.
7	M_MCOUNT	8	Message counter (M_MCOUNT) - 8 bits. To enable detection of a change of balise group message during passage of the balise group.
8	NID_C	10	Country or region.
9	NID_BG	14	Identity of the balise group.
10	Q_LINK	1	Marks the balise group as linked (Q_LINK = 1) or unlinked (Q_LINK = 0)
	Packet 0 (optional)	14	Virtual Balise Cover marker
	Information	Variable	This information is composed according to the rules applicable for packets.
	Packet 255	8	Finishing flag of the telegram

Number of bits in balise header: 50

8.4.2.2 The user information transmitted by a balise shall contain complete packets, i.e. splitting a packet between two balises is forbidden.

8.4.2.3 When used, the packet 0 shall be transmitted as the first packet of the telegram (i.e. it is appended to the header).

8.4.2.4 Note: If there is an active VBC stored on-board and in order to find a VBC marker, the ERTMS/ETCS on-board equipment needs first to check M_VERSION:

- If M_VERSION = 0.Y, the telegram will be ignored;
- If M_VERSION = 1.0, there will be no VBC marker;
- If M_VERSION = 1.1, the on-board must look for a packet 200 (see chapter 6);
- In all other cases (including when M_VERSION is higher than the highest system version supported by the on-board), the on-board must look for a packet 0.

If a packet 0 or 200 is found, the ERTMS/ETCS on-board equipment must also check whether NID_C matches the VBC marker included in the packet 0 or 200. This implies that in all future system versions the size and location of M_VERSION and NID_C inside the header, the overall size of the header and the position/content of the packet 0 appended to it, will remain invariant.

8.4.3 Rules for Euroloop messages

8.4.3.1 The format of the message to be transmitted by each loop is as follows:

General Format of Loop Message			
Field No.	VARIABLE	Length (bits)	Remarks
1	Q_UPDOWN	1	Defines the direction of the information: Down-link message (train to track) (0) Up-link message (track to train) (1)
2	M_VERSION	7	Version of the ERTMS/ETCS system.
3	Q_MEDIA	1	Defines the type of media: Loop (1)
4	NID_C	10	Country or region.
5	NID_LOOP	14	Identity of Euroloop.
	Information	Variable	This information is composed according to the rules applicable for packets.
	Packet 255	8	Finishing flag of the message

Number of bits in loop header: 33

8.4.3.2 Intentionally deleted.

8.4.4 Rules for Euroradio messages

8.4.4.1 The message identifier is unique (variable NID_MESSAGE).

8.4.4.1.1 All message identifiers not listed in 8.5.3 shall be considered as invalid values (i.e. like spare values) when received by the on-board equipment. Exception: reception of information only differing by Y with regards to the highest system version number X supported by on-board (refer to section 3.17.3.11 b)).

8.4.4.1.1.1 Note: Depending on the system version number with which the message was transmitted relevant exception from chapter 6 may apply regarding 8.5.3.

8.4.4.2 Each message shall indicate its own length through the use of the variable L_MESSAGE.

8.4.4.2.1 The receiver shall check whether the computed length of the message is equal to the length given by L_MESSAGE.

8.4.4.3 The messages shall be composed of predefined variables and packets.

8.4.4.4 For some messages, it shall be possible to add optional packets at the end of the message.

8.4.4.4.1 The track to train messages possibly including optional packets are listed hereafter:

Track to Train message	Mess. ID	Optional packets
SR Authorisation	2	63
Movement Authority	3	21, 27, 49, 80, plus common optional packets
SM Authorisation	4	3, 5, 31, 39, 40, 44, 45, 51, 58, 64, 65, 66, 67, 68, 69, 71, 73, 74, 79, 88, 131, 140
Request To Shorten MA	9	49, 80
General Message	24	From RBC: 21, 27, plus common optional packets From RIU: 44, 45, 143, 180, 254
SH authorised	28	3, 44, 49
MA with Shifted Location Reference	33	21, 27, 49, 80, plus common optional packets
Infill MA	37	5, 21, 27, 39, 40, 41, 44, 49, 51, 52, 65, 68, 69, 70, 71, 80, 88, 138, 139

8.4.4.4.1.1 The common optional packets are the following ones:

Common optional packets
3, 5, 31, 32, 39, 40, 51, 41, 42, 44, 45, 52, 57, 58, 64, 65, 66, 67, 68, 69, 70, 71, 73, 74, 79, 88, 131, 138, 139, 140, 180

8.4.4.4.2 The train to track message 136 (Train Position Report) may include the following packets:

- a) Packet 4 (Error Reporting, see section 3.16.4),
- b) Packet 5 (Train running number, see section 3.18.4.5),
- c) Packet 44 (Data used by applications outside the ERTMS/ETCS system).

8.4.4.4.3 The train to track message 157 (SoM Position Report) may include the following packets:

- a) Packet 4 (Error Reporting, see section 3.16.4),
- b) Packet 5 (Train running number, see section 5.4.3.2 A33&A34),
- c) Packet 10 (Safe consist length information for Supervised Manoeuvre, see section 5.4.3.2 A33&A34),
- d) Packet 11 (Train Data, see section 5.4.3.2 A33&A34),
- e) Packet 44 (Data used by applications outside the ERTMS/ETCS system).

8.4.4.4.4 The train to track message 132 (MA request) may include the following packet:

- a) Packet 9 (Level 2 transition information, see clauses 3.8.2.7.1&2)

8.4.4.4.5 The train to track message 131 (Request for Supervised Manoeuvre) may optionally include the following packet:

- a) Packet 12 (Default Train Data for Supervised Manoeuvre)

8.4.4.5 If needed to obtain an integer number of bytes, padding shall be added at the end of the message.

8.4.4.6 Standard format of a radio message from track to train :

8.4.4.6.1 Format:

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	Message Identification Number
2	L_MESSAGE	Message length including everything (from field 1 to padding inclusive).
3	T_TRAIN	Time Stamp from RBC (see sections 3.16.3.2 & 3.16.3.3).
4	M_ACK	Indicates whether the message must be acknowledged (or not) by the on-board equipment (message n° 146).
5	NID_LRBG	Identification Number of LRBG.
...	variables as required by NID_MESSAGE	If needed for this message. Used when sending variables which are not included in a packet.
...	packets as required by NID_MESSAGE	If needed for this message.
	Optional packets	Refer to section 8.4.4.4 of this document.
	Padding	If required.

8.4.4.6.2 Note: In section 8.7 giving the contents of the messages, the padding information is intentionally omitted.

8.4.4.6.3 The track to train message 39 (Acknowledgement of termination of a communication session) shall include the variable M_ACK set to 0. Justification: see 3.5.5.3.

8.4.4.7 Standard format of a radio message from train to track:

8.4.4.7.1 Format:

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	Message Identification Number
2	L_MESSAGE	Message length including everything (from field 1 to padding inclusive).
3	T_TRAIN	Time Stamp from Train (see chapter 3 – Data Consistency).
4	NID_ENGINE	Identity of the train.
5	variables as required by NID_MESSAGE	If needed for this message. Used when sending variables which are not included in a packet.
6	Packet 0 or 1	Train-to-track packet type 0 – Position report, or packet type 1 - Position report based on two balise groups. Not included in messages 146, 154, 155, 156 and 159.
7	Other Packets as required by NID_MESSAGE	
8	Optional packets	
	Padding	If required.

8.4.4.7.2 Exception: The position report (packet 0 or packet 1) is not included in the following messages:

- a) Message 146 (Acknowledgement),
- b) Message 154 (No compatible version supported),
- c) Message 155 (Initiation of a communication session),
- d) Message 156 (Termination of a communication session),
- e) Intentionally deleted
- f) Message 159 (Session Established).

8.4.4.7.3 Note: In section 8.6 giving the contents of the messages, the padding information is intentionally omitted.

8.5 List of radio Messages

8.5.1 Introduction

8.5.1.1 This section identifies the radio messages with corresponding Message Identifier ("Mes. Id.") and Message Name. It also gives a list of the version-invariant messages.

8.5.1.2 Intentionally deleted.

8.5.2 Train to Track radio messages

Mes. Id.	Message Name	Invariant	Transmitted to
129	Validated Train Data	No	RBC
130	Request for Shunting	No	RBC
131	Request for Supervised Manoeuvre	No	RBC
132	MA Request	No	RBC
133	Safe consist length information for Supervised Manoeuvre	No	RBC
136	Train Position Report	No	RBC, RIU
137	Request to shorten MA is granted	No	RBC
138	Request to shorten MA is rejected	No	RBC
146	Acknowledgement	No	RBC, RIU
147	Acknowledgement of Emergency Stop	No	RBC
149	Track Ahead Free Granted	No	RBC
150	End of Mission	No	RBC
153	Radio infill request	No	RIU
154	No compatible version supported	Yes	RBC, RIU
155	Initiation of a communication session	Yes	RBC, RIU
156	Termination of a communication session	Yes	RBC, RIU
157	SoM Position Report	No	RBC
158	Text message acknowledged by driver	No	RBC
159	Session Established	No	RBC, RIU

8.5.3 Track to Train radio messages

Mes. Id.	Message Name	Invariant	Transmitted by
2	SR Authorisation	No	RBC
3	Movement Authority	No	RBC
4	SM Authorisation	No	RBC
5	SM Refused	No	RBC
6	Recognition of exit from TRIP mode	No	RBC
7	Acknowledgement of safe consist length info for SM	No	RBC
8	Acknowledgement of Train Data	No	RBC
9	Request to Shorten MA	No	RBC
15	Conditional Emergency Stop	No	RBC
16	Unconditional Emergency Stop	No	RBC
18	Revocation of Emergency Stop	No	RBC
24	General message	No	RBC, RIU
27	SH Refused	No	RBC
28	SH Authorised	No	RBC
33	MA with Shifted Location Reference	No	RBC
34	Track Ahead Free Request	No	RBC
37	Infill MA	No	RIU
40	Train Rejected	No	RBC
32	RBC/RIU System Version	Yes	RBC, RIU
38	Acknowledgement of session establishment	No	RBC, RIU
39	Acknowledgement of termination of a communication session	Yes	RBC, RIU
41	Train Accepted	No	RBC
43	SoM position report confirmed by RBC	No	RBC
45	Assignment of coordinate system	No	RBC

8.6 Definition of Radio Messages from Train to Track

8.6.1 Message 129: Validated Train Data

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	Train - track packet type 11.
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	Packet 0 or 1	
6	Train data	

8.6.2 Message 130: Request for Shunting

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	Packet 0 or 1	

8.6.2.1 Message 131: Request for Supervised Manoeuvre

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	Packet 0 or 1	
6	Packet 10	
7	Optional packet	

8.6.3 Message 132: MA Request

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	Q_MARQSTREAS ON	
6	Packet 0 or 1	
7	Optional packets	

8.6.3.1 Message 133: Safe consist length information for SM

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	Packet 0 or 1	
6	Packet 10	

8.6.4 Message 136: Train Position Report

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	Packet 0 or 1	
6	Optional packets	

8.6.5 Message 137: Request to Shorten MA is granted

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	Time stamp contained in the request.
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	T_TRAIN	
6	Packet 0 or 1	

8.6.6 Message 138: Request to Shorten MA is rejected

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	Time stamp contained in the request.
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	T_TRAIN	
6	Packet 0 or 1	

8.6.7 Message 146: Acknowledgement

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	Time stamp contained in the message that is acknowledged.
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	T_TRAIN	

8.6.8 Message 147: Acknowledgement of Emergency Stop

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	Identification Number of the acknowledged Emergency Message.
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	NID_EM	
6	Q_EMERGENCY STOP	
7	Packet 0 or 1	

8.6.9 Message 149: Track Ahead Free Granted

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	Packet 0 or 1	

8.6.10 Message 150: End of Mission

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	Q_DESK	
6	Packet 0 or 1	

8.6.11 Message 153: Radio infill request

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	NID_C	identity of the country of the “target” main balise group
6	NID_BG	identity of the “target” main balise group
7	Q_INFILL	start; end of infill
8	Packet 0 or 1	

8.6.12 Message 154: No compatible version supported

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	

8.6.13 Message 155: Initiation of a communication session

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	

8.6.14 Message 156: Termination of a communication session

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	

8.6.15 Message 157: SoM Position Report

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	Q_STATUSLRBG	
6	Packet 0 or 1	
7	Optional packets	

8.6.16 Message 158: Text Message Acknowledged by Driver

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	Identity of the text message that the driver has acknowledged.
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	NID_TEXTMESSAGE	
6	Packet 0 or 1	

8.6.17 Message 159: Session established

Field No.	VARIABLE/ PACKET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	NID_ENGINE	
5	Packet 2	

8.7 Definition of Radio Messages from Track to Train

8.7.1 Message 2: SR Authorisation

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	Q_SCALE	
7	D_SR	
8	Optional packets	

8.7.2 Message 3: Movement Authority

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	Level 2 Movement Authority	Packet 15
7	Optional packets	

8.7.2.1 Message 4: SM Authorisation

Field No.	VARIABLE/PACK ET	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	T_TRAIN	Time stamp of the Supervised Manoeuvre request
7	Q_SCALE	
8	D_REF	Reference Distance
9	V_SM	Supervised Manoeuvre mode speed limit
10	Level 2 Movement Authority	Packet 15
11	Gradient profile	Packet 21
12	International Static Speed Profile	Packet 27
13	Optional packets	

8.7.2.2 Message 5: SM Refused

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	T_TRAIN	Time stamp of the Supervised Manoeuvre request

8.7.3 Message 6: Recognition of exit from TRIP mode

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	

8.7.3.1 Message 7: Acknowledgment of safe consist length info for SM

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	T_TRAIN	Time stamp of the message Safe consist length info for SM

8.7.4 Message 8: Acknowledgement of Train Data

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	T_TRAIN	Reference to received train data message

8.7.5 Message 9: Request to Shorten MA

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	Packet 15
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	Level 2 Movement Authority	
7	Optional packets	

8.7.6 Message 15: Conditional Emergency Stop

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	Identification Number of the Emergency Stop Message.
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	NID_EM	
7	Q_SCALE	
8	D_REF	
9	Q_DIR	
10	D_EMERGENCYSTOP	

8.7.7 Message 16: Unconditional Emergency Stop

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	Identification Number of the Emergency Stop Message.
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	NID_EM	

8.7.8 Message 18: Revocation of Emergency Stop

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	Identification Number of the Emergency Stop Message.
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	NID_EM	

8.7.9 Message 24: General message

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	Optional packets	

8.7.10 Message 27: SH Refused

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	Time stamp of the shunting request.
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	T_TRAIN	

8.7.11 Message 28: SH Authorised

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	Time stamp of the shunting request.
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	T_TRAIN	
7	Optional packets	

8.7.12 Message 32: RBC/RIU System Version

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	Version of the ERTMS/ETCS system.
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	M_VERSION	

8.7.13 Message 33: MA with Shifted Location Reference

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	Q_SCALE	
7	D_REF	Reference Distance
8	Level 2 Movement Authority	Packet 15
9	Optional packets	

8.7.14 Message 34: Track Ahead Free Request

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	Q_SCALE	
7	D_REF	
8	Q_DIR	
9	D_TAFDISPLAY	
10	L_TAFDISPLAY	

8.7.15 Message 37: Infill MA

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	Infill Location Reference	Packet 136
7	Level 1 Movement Authority	Packet 12
8	Optional packets	

8.7.16 Message 38: Acknowledgement of session establishment

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	

8.7.17 Message 39: Acknowledgement of termination of a communication session

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	

always set to 0

8.7.18 Message 40: Train Rejected

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	

8.7.19 Message 41: Train Accepted

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	

8.7.20 Intentionally deleted**8.7.21 Message 43: SoM position report confirmed by RBC**

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	

8.7.22 Message 45: Assignment of coordinate system

Field No.	VARIABLE	Remarks
1	NID_MESSAGE	
2	L_MESSAGE	
3	T_TRAIN	
4	M_ACK	
5	NID_LRBG	
6	Q_ORIENTATION	